

maxon

IDX

Application Notes



idx.maxongroup.com

IDX Drives
Application Notes
CCMC | Edition 2021-03 | DocID rel9613

TABLE OF CONTENTS

1 ABOUT	5
1.1 About this Document	5
1.2 About the Devices	8
1.3 About the Safety Precautions	9
2 CONTROLLER ARCHITECTURE	11
2.1 In Brief	11
2.2 Overview	12
2.3 Regulation Methods	12
2.3.1 Current Regulation	12
2.3.2 Velocity Regulation (with Feedforward)	13
2.3.3 Position Regulation (with Feedforward)	17
2.3.4 Operation Modes with Feedforward	18
2.4 Regulation Tuning	19
3 FIRMWARE UPDATE WITHOUT USE OF «EPOS STUDIO»	21
3.1 In Brief	21
3.2 Preconditions	22
3.3 Firmware Update via USB	24
3.4 Firmware Update via CANopen	24
3.5 Firmware Update via EtherCAT	25
3.6 Steps: How to	25
3.6.1 Prepare Controller	25
3.6.2 Download «Program Data File» (CiA 302-3)	26
3.6.3 Download «Program Data File» (FoE)	27
3.6.4 Check Identity	27
3.7 Object Dictionary	28

READ THIS FIRST

THESE INSTRUCTIONS ARE INTENDED FOR QUALIFIED TECHNICAL PERSONNEL. PRIOR COMMENCING WITH ANY ACTIVITIES...

- you must carefully read and understand this manual and
- you must follow the instructions given therein.

IDX DRIVES ARE CONSIDERED AS PARTLY COMPLETED MACHINERY ACCORDING TO EU DIRECTIVE 2006/42/EC, ARTICLE 2, CLAUSE (G) AND ARE INTENDED TO BE INCORPORATED INTO OR ASSEMBLED WITH OTHER MACHINERY OR OTHER PARTLY COMPLETED MACHINERY OR EQUIPMENT.

THEREFORE, YOU MUST NOT PUT THE DEVICE INTO SERVICE,...

- unless you have made completely sure that the other machinery fully complies with the EU directive's requirements!
- unless the other machinery fulfills all relevant health and safety aspects!
- unless all respective interfaces have been established and fulfill the herein stated requirements!

4 CANOPEN BASIC INFORMATION	29
4.1 In Brief	29
4.2 Network Structure	30
4.3 Configuration	31
4.4 SDO Communication	35
4.4.1 Expedited SDO Protocol	35
4.4.2 SDO Communication Examples.	37
4.4.3 EPOS Studio Command Analyzer.....	39
4.5 PDO Communication	41
4.5.1 PDO Transmissions	42
4.5.2 PDO Mapping	43
4.5.3 PDO Configuration	43
4.6 Heartbeat Protocol.	47
5 ETHERCAT COMMUNICATION & MASTER INTEGRATION	49
5.1 In Brief	49
5.2 Setup of Windows Defender Firewall for EtherCAT Communication.	50
5.2.1 Add a new Firewall Rule	50
5.2.2 Modify an existing Firewall Rule.	54
5.3 Beckhoff TwinCAT Integration	57
5.3.1 Integrating ESI Files.	57
5.3.2 How to export the ESI File	57
5.3.3 Scanning the EtherCAT Slave Device	58
5.3.4 Configuration for commanding in a Cyclic Synchronous Mode	61
5.3.5 Changing PDO Mapping using Beckhoff TwinCAT	62
5.3.6 Configuration of the Axis	65
5.4 zub MACS Integration	71
5.4.1 EPOS4/IDX: Configuration Tasks	73
5.4.2 MasterMACS / MACS5: Setup Tasks	74
5.4.3 MACS: Configuration of EtherCAT Communication & Start-up Procedure	75
5.4.4 Simple Application Program.	79
5.5 OMRON Sysmac NJ Integration	80

6 DEVICE PROGRAMMING	93
6.1 In Brief	93
6.2 First Step	94
6.3 Homing Mode (HMM)	95
6.4 Profile Position Mode (PPM)	96
6.5 Profile Velocity Mode (PVM)	98
6.6 Cyclic Synchronous Position Mode (CSP)	99
6.7 Cyclic Synchronous Velocity Mode (CSV)	100
6.8 Cyclic Synchronous Torque Mode (CST)	101
6.9 State Machine	102
6.10 Motion Info	103
6.11 Utilities	104
LIST OF FIGURES	105
LIST OF TABLES	108
INDEX	110

1 ABOUT

1.1 About this Document

1.1.1 Intended Purpose

The purpose of the present document is to provide you specific information to cover particular cases or scenarios that might come in handy during commissioning of your drive system.

Use for other and/or additional purposes is not permitted. maxon, the manufacturer of the equipment described, does not assume any liability for loss or damage that may arise from any other and/or additional use than the intended purpose.

The present document is part of a documentation set. The below overview shows the documentation hierarchy and the interrelationship of its individual parts:




Figure 1-1 Documentation structure

1.1.2 Target Audience

This document is meant for trained and skilled personnel working with the equipment described. It conveys information on how to understand and fulfill the respective work and duties.

This document is a reference book. It does require particular knowledge and expertise specific to the equipment described.

1.1.3 How to use

Take note of the following notations and codes which will be used throughout the document.

Notation	Explanation
«Abcd»	indicating a title or a name (such as of document, product, mode, etc.)
¤Abcd¤	indicating an action to be performed using a software control element (such as folder, menu, drop-down menu, button, check box, etc.) or a hardware element (such as switch, DIP switch, etc.)
(n)	referring to an item (such as order number, list item, etc.)
*	referring to an internal value
***	referring to a not yet implemented item
➔	denotes “see”, “see also”, “take note of”, or “go to”

Table 1-1 Notations used

In the later course of the present document, the following abbreviations and acronyms will be used:

Short form	Meaning
EPOS4	hardware and/or firmware functionalities based on maxon EPOS4 platform
IDX	any type of IDX drive
IDX 56	any type of IDX 56 drive
IDX 56 CANopen	IDX 56 drive with positioning controller and CANopen interface
IDX 56 EtherCAT	IDX 56 drive with positioning controller and EtherCAT interface
IDX 56 I/O	IDX 56 drive with speed controller and I/O interface
IDX 70	any type of IDX 70 drive
IDX 70 CANopen	IDX 70 drive with positioning controller and CANopen interface
IDX 70 EtherCAT	IDX 70 drive with positioning controller and EtherCAT interface
IDX 70 I/O	IDX 70 drive with speed controller and I/O interface

Table 1-2 Abbreviations and acronyms used

1.1.4 Symbols and Signs



Requirement / Note / Remark

Indicates an action you must perform prior continuing or refers to information on a particular item.



Best Practice

Gives advice on the easiest and best way to proceed.



Material Damage

Points out information particular to potential damage of equipment.

1.1.5 Trademarks and Brand Names

For easier legibility, registered brand names are listed below and will not be further tagged with their respective trademark. It must be understood that the brands (the below list is not necessarily concluding) are protected by copyright and/or other intellectual property rights even if their legal trademarks are omitted in the later course of this document.

Brand name	Trademark owner
Adobe® Reader®	© Adobe Systems Incorporated, USA-San Jose, CA
APOSS®	© zub machine control AG, CH-Rothenburg
CANopen® CiA®	© CiA CAN in Automation e.V, DE-Nuremberg
EtherCAT®	© EtherCAT Technology Group, DE-Nuremberg, licensed by Beckhoff Automation GmbH, DE-Verl
Sysmac	© OMRON Corporation, JP-Kyoto
TwinCAT®	© Beckhoff Automation GmbH, DE-Verl
Windows®	© Microsoft Corporation, USA-Redmond, WA

Table 1-3 Brand names and trademark owners

1.1.6 Sources for additional Information

For further details and additional information, please refer to below listed sources:

#	Reference
[1]	IEC/EN 60204-1: Safety of machinery – Electrical equipment of machines
[2]	IEC/EN 61800-5-2: Adjustable speed electrical power drive systems
[3]	CiA 301 CANopen application layer and communication profile www.can-cia.org
[4]	CiA 305 Layer Setting Services (LSS) and protocols www.can-cia.org
[5]	CiA 402 CANopen device profile for drives and motion control www.can-cia.org

Table 1-4 Sources for additional information

1.1.7 Copyright

This document is protected by copyright. Any further use (including reproduction, translation, microfilming, and other means of electronic data processing) without prior written approval is not permitted. The mentioned trademarks belong to their respective owners and are protected under intellectual property rights.
© 2021 maxon. All rights reserved. Subject to change without prior notice.

CCMC | IDX Application Notes | Edition 2021-03 | DocID rel9613

maxon motor ag
Brünigstrasse 220 +41 41 666 15 00
CH-6072 Sachseln www.maxongroup.com

1.2 About the Devices

maxon's «IDX» are compact, high-performance, IP65-protected, brushless DC drives with either integrated positioning controller or speed controller particularly suitable for the use in harsh environmental conditions. They deliver a high continuous torque and come in a wide range of configurable options that allow full adaptation to suit specific needs.

The IDX firmware is based on maxon's EPOS4 platform. Therefore, some of the content covered in the present application notes is identical or similar to EPOS4.

1.3 About the Safety Precautions

IMPORTANT NOTICE: PREREQUISITES FOR PERMISSION TO COMMENCE INSTALLATION

IDX drives are considered as partly completed machinery according to EU Directive 2006/42/EC, Article 2, Clause (g) and **are intended to be incorporated into or assembled with other machinery or other partly completed machinery or equipment.**



WARNING

Risk of Injury

Operating the device without the full compliance of the surrounding system with the EU directive 2006/42/EC may cause serious injuries!

- *Do not operate the device, unless you have made sure that the other machinery fulfills the requirements stated in EU directive!*
- *Do not operate the device, unless the surrounding system fulfills all relevant health and safety aspects!*
- *Do not operate the device, unless all respective interfaces have been established and fulfill the stated requirements!*

SAFETY FIRST!

*Keep in mind:
Safety first!
Always!*

- Do not engage with any work unless you possess the stated skills (→chapter “1.1.2 Target Audience” on page 1-5)!
- Refer to →chapter “1.1.4 Symbols and Signs” on page 1-6 to understand the subsequently used indicators!
- You must observe any regulation applicable in the country and/or at the site of implementation with regard to health and safety/accident prevention and/or environmental protection!



DANGER

High voltage and/or electrical shock

Touching live wires causes death or serious injuries!

- Consider any power cable as connected to live power, unless having proven the opposite!
- Make sure that neither end of cable is connected to live power!
- Make sure that power source cannot be engaged while work is in process!
- Obey lock-out/tag-out procedures!
- Make sure to securely lock any power engaging equipment against unintentional engagement and tag it with your name!



Requirements

- Make sure that all associated devices and components are installed according to local regulations.
- Be aware that, by principle, an electronic apparatus cannot be considered fail-safe. Therefore, you must make sure that any machine/apparatus has been fitted with independent monitoring and safety equipment. If the machine/apparatus should break down, if it is operated incorrectly, if the control unit breaks down or if the cables break or get disconnected, etc., the complete drive system must return – and be kept – in a safe operating mode.
- Be aware that you are not entitled to perform any repair on components supplied by maxon.

Continued on next page.



Electrostatic sensitive device (ESD)

- Wear working cloth and use equipment in compliance with ESD protective measures.
- Handle devices with extra care.

2 CONTROLLER ARCHITECTURE

CONTENT

In Brief	2-11
Overview	2-12
Regulation Methods	2-12
Regulation Tuning	2-19

2.1 In Brief

A wide variety of operating modes permit flexible configuration of drive and automation systems by using positioning, speed and current regulation. The built-in interface allows online commanding by CAN or EtherCAT bus master units as well as networking to multiple axes drives.

Good quality velocity PI control is made possible by the use of algorithms for estimating the motor rotation velocity from the measured rotor position that are based either on a low pass filter or on a velocity observer.

OBJECTIVE

The present application note explains the EPOS4/IDX controller architecture.

In addition to PID position regulation, the functionalities of the built-in acceleration and velocity feedforward are described.

The functionality of the velocity PI controller, the low pass filter, and the observer used for estimating the velocity are described. The benefits of each velocity estimation method are highlighted and illustrated by using practical examples.

SCOPE

Hardware	Order #	Firmware version	Reference
EPOS4/IDX	–	0160h	IDX Firmware Specification
IDX 56	various	0160h or higher	
IDX 70	various	0170h or higher	

Table 2-5 Controller architecture | Covered hardware and required documents

TOOLS

Tools	Description
Software	«EPOS Studio» Version 3.6 or higher

Table 2-6 Controller architecture | Recommended tools

2.2 Overview

The EPOS4/IDX controller architecture contains three built-in control loops.

- Current regulation is used in all modes.
- Position or velocity regulation is only used in position-based or velocity-based modes, respectively.




Figure 2-2 Controller architecture | Overview

2.3 Regulation Methods

2.3.1 Current Regulation

During a movement within a drive system, forces and/or torques must be controlled. Therefore, as a principal regulation structure, EPOS4/IDX offers current-based control.




Figure 2-3 Controller architecture | Current regulator

CONSTANTS

Sampling period: $T_s = 0.04\text{ms}$

OBJECT DICTIONARY ENTRIES

Symbol	Unit	Name	Index	Subindex
K_{P_EPOS4}	$\frac{mV}{A}$	Current controller P gain	0x30A0	0x01
K_{I_EPOS4}	$\frac{mV}{A \cdot ms}$	Current controller I gain	0x30A0	0x02

Table 2-7 Controller architecture | Current regulation – Object dictionary

CONVERSION OF PI CONTROLLER PARAMETERS (EPOS4/IDX TO SI UNITS)

$$K_{P_SI} = 0.001 \cdot K_{P_EPOS4}$$

$$K_{I_SI} = K_{I_EPOS4}$$

Current controller parameters in SI units can be used in analytical or numerical simulations via the following transfer function:

$$C_{current}(s) = K_{P_SI} + \frac{K_{I_SI}}{s}$$

ANTI-WINDUP

In order to prevent degradation of the control performance when the control input stays at the limit value for long time, an anti-windup algorithm is implemented preventing the integral part of the PI controller to take values larger than the ones bound on the control input.

TRANSPORT DELAY OF THE CONTROL LOOP

Total transport delay of the current regulation loop is always smaller than 0.06 ms.

2.3.2 Velocity Regulation (with Feedforward)

EPOS4/IDX offers velocity regulation based on the subordinated current control.




Figure 2-4 Controller architecture | Velocity regulator with feedforward

CONSTANTS

Sampling period: $T_s = 0.4ms$

OBJECT DICTIONARY ENTRIES FOR CONTROLLER

Symbol	Unit	Name	Index	Subindex
$K_{P\omega_EPOS4}$	$\frac{mA \cdot s}{rad}$	Velocity controller P gain	0x30A2	0x01
$K_{I\omega_EPOS4}$	$\frac{mA}{rad}$	Velocity controller I gain	0x30A2	0x02
FF_{ω_EPOS4}	$\frac{mA \cdot s}{rad}$	Velocity controller FF velocity gain	0x30A2	0x03
FF_{α_EPOS4}	$\frac{mA \cdot s^2}{rad}$	Velocity controller FF acceleration gain	0x30A2	0x04
f	$\frac{1}{s}$	Velocity controller filter cut-off frequency	0x30A2	0x05

Table 2-8 Controller architecture | Velocity regulation – Object dictionary

CONVERSION OF PI CONTROLLER PARAMETERS (EPOS4/IDX TO SI UNITS)

$$K_{P\omega_SI} = 0.001 \cdot K_{P\omega_EPOS4}$$

$$K_{I\omega_SI} = 0.001 \cdot K_{I\omega_EPOS4}$$

$$FF_{\omega_SI} = 0.001 \cdot FF_{\omega_EPOS4}$$

$$FF_{\alpha_SI} = 0.001 \cdot FF_{\alpha_EPOS4}$$

Velocity controller parameters in SI units can be used in analytical or numerical simulations via transfer function for the PI controller:

$$C_{velocity}(s) = K_{P\omega_SI} + \frac{K_{I\omega_SI}}{s}$$

ANTI-WINDUP

An anti-windup algorithm is implemented to prevent integration wind-up in PI controller, when the actuators are saturated.

LOW PASS FILTER

The estimation of the motor velocity can be done by using the measured time between consecutive sensor edges, which is low pass filtered in order to eliminate the effects of measurement noise. The transfer function of the low pass filtered estimation functionality that can be used in simulations has the following form:

$$C_{FilterEstimator}(s) = \frac{2 \cdot \pi \cdot f}{s + 2 \cdot \pi \cdot f}$$

OBSERVER

An alternative to the low pass filter is the use of an observer. Thereby, the observed velocity is calculated in two steps. First; prediction of the velocity, position, and external torque, based on the parameters that define the mechanical transfer function of the system. Second; correction of the predicted values based on the newly measured rotor position.

OBJECT DICTIONARY ENTRIES FOR OBSERVER

Symbol	Unit	Name	Index	Subindex
k_{m_EPOS4}	$\frac{mNm}{A}$	Torque constant	0x3001	0x05
l_{θ_EPOS4}	1	Velocity observer position correction gain	0x30A3	0x01
l_{ω_EPOS4}	Hz	Velocity observer velocity correction gain	0x30A3	0x02
l_{T_EPOS4}	$\frac{mNm}{rad}$	Velocity observer load correction gain	0x30A3	0x03
r_{EPOS4}	$\frac{\mu Nm}{rpm}$	Velocity observer friction	0x30A3	0x04
J_{EPOS4}	$g \cdot cm^2$	Velocity observer inertia	0x30A3	0x05

Table 2-9 Controller architecture | Velocity observer – Object dictionary

All parameters relevant for the observer operation can be entered either manually or can be obtained from the EPOS4/IDX auto tuning procedure. The auto tuning automatically executes the identification experiments, identifies the relevant parameters that characterize the drive train, and calculates the values of the observer correction gains.

CONVERSION OF OBSERVER PARAMETERS (EPOS4/IDX TO SI UNITS)

$$k_{m_SI} = 0.001 \cdot k_{m_EPOS4}$$

$$J_{SI} = 0.0000001 \cdot J_{EPOS4}$$

$$r_{SI} = \frac{0.00003}{\pi} \cdot r_{EPOS4}$$

$$l_{\theta_SI} = l_{\theta_EPOS4}$$

$$l_{\omega_SI} = l_{\omega_EPOS4}$$

$$l_{T_SI} = 0.001 \cdot l_{T_EPOS4}$$

The transfer functions characterizing the two steps in the observer calculations and that can be used in numerical simulation of the velocity controller with observer are the following:

PREDICTION STEP

$$\theta_{Observed} = \frac{\omega_{Observed}}{s}$$

$$\omega_{Observed} = \frac{k_{M_SI} \cdot i_{Measured} - T_{Observed}}{J_{SI} \cdot s + r_{SI}}$$

CORRECTION STEP

$$\theta_{Observed} = \theta_{Observed} + l_{\theta_SI} \cdot (\theta_{Measured} - \theta_{Observed})$$

$$\omega_{Observed} = \omega_{Observed} + l_{\omega_SI} \cdot (\theta_{Measured} - \theta_{Observed})$$

$$T_{Observed} = T_{Observed} + l_{T_SI} \cdot (\theta_{Measured} - \theta_{Observed})$$

WHEN SHOULD THE LOW PASS FILTER BE USED TO ESTIMATE THE VELOCITY?

The estimation of the motor velocity based on measuring the time between consecutive sensor edges and low pass filtering does not rely on any additional information on the mechanical system to which the motor is attached. Therefore, it is suitable in cases when there is no information on the mechanical properties of the system available or when the characteristics of the system change significantly over time.

Typical examples are cases in which the moment of inertia or viscous friction that the motor encounters change significantly during operation.

The solution with the filter gives good results in cases when a high-resolution position sensor is used and when the motor is operated at relatively high velocities (more than 20% of nominal motor speed). However, in cases when the resolution of the position sensor is low and/or the motor operates at low speed, the estimation with the observer results in a better control performance.

WHEN SHOULD THE OBSERVER BE USED TO ESTIMATE THE VELOCITY?

In order to use the observer for estimating the rotational velocity of the motor, parameters, such as inertia and viscous friction coefficient of the drive system, need to be known and must be stable over time and should not change a lot during operation. In EPOS4/IDX, there is an option to identify all the required parameters by using the «Auto Tuning Wizard».

The use of the observer brings most advantages when the position feedback sensor has a low resolution. Typical example is the use of Hall sensors for feedback instead of an incremental encoder, or the use of incremental encoders with up to 500 counts per turn. In general, the use of the observer provides a less noisy estimation of the rotor velocity resulting in better regulation and less audible noise especially at low operational velocities.

In addition, the velocity observer can be set stiffer (compared to the case when the filter is used) due to better quality of the estimated feedback signal resulting in a very good dynamical response.

However, when encoders with high resolution (above 500 counts per turn) are used, the performance of the system with observer is similar to its performance in the case when the low pass filter is used.

TRANSPORT DELAY OF THE CONTROL LOOP

Total transport delay of the velocity regulation loop is always smaller than 0.4 ms.

2.3.3 Position Regulation (with Feedforward)

EPOS4/IDX is able to close a positioning control loop based on the subordinated current control.




Figure 2-5 Controller architecture | Position regulator with feedforward

CONSTANTS

Sampling period: $T_s = 0.4\text{msec}$

OBJECT DICTIONARY ENTRIES

Symbol	Unit	Name	Index	Subindex
K_{PP_EPOS4}	$\frac{mA}{rad}$	Position controller P gain	0x30A1	0x01
K_{IP_EPOS4}	$\frac{mA}{rad \cdot s}$	Position controller I gain	0x30A1	0x02
K_{DP_EPOS4}	$\frac{mA \cdot s}{rad}$	Position controller D gain	0x30A1	0x03
FF_{ω_EPOS4}	$\frac{mA \cdot s}{rad}$	Position controller FF velocity gain	0x30A1	0x04
FF_{α_EPOS4}	$\frac{mA \cdot s^2}{rad}$	Position controller FF acceleration gain	0x30A1	0x05

Table 2-10 Controller architecture | Position regulation – Object dictionary

The position controller is implemented as PID controller. To improve the motion system's setpoint following, positioning regulation is supplemented by feedforward control. Thereby, velocity feedforward serves for compensation of speed-proportional friction, whereas acceleration feedforward considers known inertia. In addition, the differential part of the PID Controller signal is low pass filtered before it is added to the proportional and integral part. Low pass filtering is done to prevent negative influence on the control performance by the differentiation of noisy measured motor position.

CONVERSION OF PI CONTROLLER PARAMETERS (EPOS4/IDX TO SI UNITS)

$$K_{PP_SI} = 0.001 \cdot K_{P_EPOS4}$$

$$K_{IP_SI} = 0.001 \cdot K_{I_EPOS4}$$

$$K_{DP_SI} = 0.001 \cdot K_{D_EPOS4}$$

$$FF_{\omega_SI} = 0.001 \cdot FF_{\omega_EPOS4}$$

$$FF_{\alpha_SI} = 0.001 \cdot FF_{\alpha_EPOS4}$$

Position controller parameters in SI units can be used in analytical or numerical simulations via transfer function:

$$C_{position}(s) = K_{PP_SI} + \frac{K_{IP_SI}}{s} + \frac{K_{DP_SI} \cdot s}{1 + \frac{K_{DP_SI}}{10 \cdot K_{PP_SI}} \cdot s}$$

ANTI-WINDUP

The anti-windup method is used to prevent integration wind-up in PID controller when the actuators are saturated.

2.3.4 Operation Modes with Feedforward

Acceleration and velocity feedforward are effective in «Profile Position Mode» (PPM), «Profile Velocity Mode» (PVM), and «Homing Mode» (HMM). All other operating modes are not affected.

PURPOSE OF VELOCITY FEEDFORWARD

Velocity feedforward provides additional current in cases, where the load increases with speed, such as speed-dependent friction. The load is assumed to proportionally increase with speed. The optimal velocity feedforward parameter in SI units is:

$$FF_{\omega_SI} = \frac{r_{SI}}{k_{m_SI}}$$

Meaning: With given total friction proportional factor in SI units r_{SI} relative to the motor shaft, and the motor's torque constant also in SI units k_{m_SI} , you ought to adjust the velocity feedforward parameter to:

$$FF_{\omega_EPOS4} = 1000 \cdot FF_{\omega_SI} = 1000 \cdot \frac{r_{SI}}{k_{m_SI}}$$

PURPOSE OF ACCELERATION FEEDFORWARD

Acceleration feedforward provides additional current in cases of high acceleration and/or high load inertias.
The optimal acceleration feedforward parameter in SI units is:

$$FF_{a_SI} = \frac{J_{SI}}{k_{m_SI}}$$

Meaning: With given total inertia in SI units J_{SI} relative to the motor shaft, and the motor's torque constant in SI units k_{m_SI} , you ought to adjust the acceleration feedforward parameter to:

$$FF_{\alpha_EPOS4} = 1000 \cdot FF_{a_SI} = 1000 \cdot \frac{J_{SI}}{k_{m_SI}}$$

TRANSPORT DELAY OF THE CONTROL LOOP

Total transport delay of the position regulation loop is always smaller than 0.4 ms.

2.4 Regulation Tuning

maxon's «EPOS Studio» features regulation tuning as a powerful wizard allowing to automatically tune all controller, estimator, and feedforward parameters described above for most drive systems within a few minutes.

••page intentionally left blank••

3 FIRMWARE UPDATE WITHOUT USE OF «EPOS STUDIO»

CONTENTS

In Brief	3-21
Preconditions	3-22
Firmware Update via USB	3-24
Firmware Update via CANopen	3-24
Firmware Update via EtherCAT	3-25
Steps: How to...	3-25
Object Dictionary	3-28

3.1 In Brief

OBJECTIVE

The present application note explains how to carry out a firmware update of an EPOS4/IDX drive without the use of the «EPOS Studio» directly via the existing bus systems. The compatibility of the various versions as well as the necessary implementation sequences for the different communication interfaces are described.

SCOPE

Hardware	Order #	Firmware version	Reference
EPOS4/IDX	–	0160h	IDX Firmware Specification
IDX 56	various	0160h or higher	
IDX 70	various	0170h or higher	

Table 3-11 EtherCAT integration | Covered hardware and required documents

TOOLS

Tools	Description
Software	«EPOS Studio» Version 3.6 or higher (required for initial export of Program Data File, only)

Table 3-12 EtherCAT integration | Recommended tools

3.2 Preconditions

SUPPORTED INTERFACES

The IDX drive supports the following communication interfaces:

- USB
- CANopen
- EtherCAT

The firmware version 0x0160 or higher is required.

The firmware update sequence requires a «Program Data File» containing the desired firmware version. These files are exported using the «EPOS Studio».

STARTING «EPOS STUDIO»

- 1) Make sure you installed «EPOS Studio» version 3.6 (or higher) on your PC.
If not the case, download the latest version here: →<http://epos.maxongroup.com>
- 2) Start «EPOS Studio» without creating a new project. Thereby, an online connection to an IDX drive is not necessary.

EXPORTING «PROGRAM DATA FILE»

- 1) In the main menu «Extras», open the dialog «Firmware File Registration».
- 2) Add a firmware file and click the «Add File» button.




Figure 3-6 Firmware update without «EPOS Studio» | Open firmware file registration dialog

- 3) Select the firmware and click right to open the context menu, then click «Export Program Data File».




Figure 3-7 Firmware update without «EPOS Studio» | Export program data file

- 4) Select the directory to export file and click «OK».




Figure 3-8 Firmware update without «EPOS Studio» | Select export directory

- 5) Click «OK» to confirm.




Figure 3-9 Firmware update without «EPOS Studio» | Confirm export directory

- 6) Check the exported firmware file (*.msdc).



Figure 3-10 Firmware update without «EPOS Studio» | Check firmware file

3.3 Firmware Update via USB

SUPPORTED UPDATE PATHS

The following table shows the compatibility of a given firmware version for direct update via the USB interface.

OLD firmware version	NEW firmware version	
	0x0160	higher
0x0160		✓
higher	✓	

Table 3-13 Firmware update without «EPOS Studio» | USB – Old vs. new firmware version

SEQUENCE

Steps

- Prepare controller (→“Prepare Controller” on page 3-25)
- Download «program data file» (CiA 302-3) “IDX_wwwwh_xxxh_yyyh_zzzh.msdc”
(→“Download «Program Data File» (CiA 302-3)” on page 3-26)
- Check identity (→“Check Identity” on page 3-27)

3.4 Firmware Update via CANopen

SUPPORTED UPDATE PATHS

The following table shows the compatibility of a given firmware version for direct update via the CANopen interface.

OLD firmware version	NEW firmware version	
	0x0160	higher
0x0160		✓
higher	✓	

Table 3-14 Firmware update without «EPOS Studio» | CANopen – Old vs. new firmware version

SEQUENCE

Steps

- Prepare controller (→“Prepare Controller” on page 3-25)
- Download «program data file» (CiA 302-3) “IDX_wwwwh_xxxh_yyyh_zzzh.msdc”
(→“Download «Program Data File» (CiA 302-3)” on page 3-26)
- Check identity (→“Check Identity” on page 3-27)

3.5 Firmware Update via EtherCAT

SUPPORTED UPDATE PATHS

The following table shows the compatibility of a given firmware version for direct update via the EtherCAT interface.

OLD firmware version	NEW firmware version	
	0x0160	higher
0x0160		✓
higher	✓	

Table 3-15 Firmware update without «EPOS Studio» | EtherCAT – Old vs. new firmware version

SEQUENCE

Steps

- Prepare controller (→“Prepare Controller” on page 3-25)
- Download «program data file» (FoE) “IDX_wwwwh_xxxh_yyyh_zzzzh.msdc” (→“Download «Program Data File» (FoE)” on page 3-27)
- Check identity (→“Check Identity” on page 3-27)

3.6 Steps: How to...

The following section describes the implementation of the required steps during the different firmware update sequences.

3.6.1 Prepare Controller




Table 3-16 Firmware update without «EPOS Studio» | How to prepare the controller

3.6.2 Download «Program Data File» (CiA 302-3)

#	Step	Description		
A	Change to device control state «Pre-Operational» [a]	→separate document «IDX Communication Guide»; chapter “CAN Communication”		
B	Check NMT state [a]			
C	Stop program [b]	Write «Stop» to object «Program Control» Object 0x1F51-01 Value 0x00 (Stop) Timeout 10 ms		
D	Wait until program is stopped	Read value from object «Program Control» Object 0x1F51-01 Expected value 0x00 (Stopped) Wait timeout 10'000 ms		
E	Clear program	Write «Clear» to object «Program Control» Object 0x1F51-01 Value 0x03 (Clear) Timeout 20'000 ms		
F	Download program	Write file content to object «Program Data» Object 0x1F50-00 File IDX_wwwwh_xxxh_yyyyh_zzzzh.msdc Timeout 10'000 ms		
G	Start program [b]	Write «Start» to object «Program Control» Object 0x1F51-01 Value 0x01 (start) Timeout 10 ms		
H	Wait until program is started	Read value from object «Program Control» Object 0x1F51-01 Expected value 0x01 (Started) Wait timeout 10'000 ms		

[a] only for CANopen interface

[b] During starting or stopping the program, the communication protocol is aborted. The controller does not respond to the received command. Reduce timeout and do not check communication result.

Table 3-17 Firmware update without «EPOS Studio» | How to download the program data file (CiA 302-3)

3.6.3 Download «Program Data File» (FoE)




Table 3-18 Firmware update without «EPOS Studio» | How to download the program data file (FoE)

3.6.4 Check Identity




Table 3-19 Firmware update without «EPOS Studio» | How to check identity

3.7 Object Dictionary

OBJECTS IN «STOPPED» STATE

While the program is stopped, only a few objects are accessible.

Index	Name
0x1000-00	Device type
0x1008-00	Manufacturer device name
0x1018-01	Identity – Vendor-ID
0x1018-02	Identity – Product code
0x1018-03	Identity – Revision number
0x1018-04	Identity – Serial number
0x1F50-00	Program data
0x1F51-00	Program control
0x1F56-00	Program software identification

Table 3-20 Firmware update without «EPOS Studio» | Objects in «Stopped» state

OBJECTS VALUES IN «STOPPED» STATE

While the program is stopped, the displayed values of the following objects differ.

Index	Name	Program started Application active	Program stopped Bootloader active
0x1000-0x00	Device type	0x00020192	0x0000012E
0x1018-0x02	Product code	<ul style="list-style-type: none">• High word: Hardware version• Low word: Application number	<ul style="list-style-type: none">• High word: Hardware version• Low word: 0x0000
0x1018-0x03	Revision number	<ul style="list-style-type: none">• High word: Software version• Low word: Application version	<ul style="list-style-type: none">• High word: 0x0000• Low word: 0x0000

Table 3-21 Firmware update without «EPOS Studio» | Objects values in «Stopped» state

4 CANOPEN BASIC INFORMATION

CONTENTS

Network Structure	4-30
Configuration	4-31
SDO Communication	4-35
PDO Communication	4-41
Heartbeat Protocol	4-47

4.1 In Brief

A wide variety of operating modes permit flexible configuration of drive and automation systems by using positioning, speed and current regulation. The built-in CANopen interface allows networking to multiple drives as well as online commanding by CAN bus master units.

For fast communication with several IDX drive, we suggest to use the CANopen protocol. The individual devices within the network are commanded by one common CANopen master.

OBJECTIVE

The present Application Note explains the functionality of the CANopen structure and protocol. It also describes the configuration process in a step-by-step procedure.

SCOPE

Hardware	Order #	Firmware version	Reference
EPOS4/IDX	–	0160h	IDX Firmware Specification
IDX 56	various	0160h or higher	
IDX 70	various	0170h or higher	

Table 4-22 CANopen basic information | Covered hardware and required documents

TOOLS

Tools	Description
Software	«EPOS Studio» Version 3.60 or higher

Table 4-23 CANopen basic information | recommended tools

4.2 Network Structure

maxon IDX drives' CAN interface follows the CANopen specifications CiA 301 V4.2 «CANopen application layer and communication profile» and CiA 402 V3.0 «Drives and motion control device profile».




Figure 4-11 CANopen basic information | Topology with external bus termination (example)

The CAN bus line must be terminated at both ends using a termination resistor of typically $120\ \Omega$. For the IDX, a ready-made termination resistor available with maxon P/N 662933.

4.3 Configuration

Follow below step-by-step instructions for correct CAN communication setup.

4.3.1 Step 1: CANopen Master

Use one of the PC/CAN interface cards or PLCs listed below. For all of them, motion control libraries, examples and documentation are available on the Internet (for URLs → page 1-7).

Recommended Component	Manufacturer / Contact	Supported Product	maxon Motion Control Library [c]
PC/CAN Interface Card [a]	IXXAT www.ixxat.de	All offered CANopen cards	Windows 32-Bit/64-Bit DLL Linux 32-Bit/64-Bit (Intel x86) Linux 32-Bit (ARM V7/V8)
	Kvaser www.kvaser.com	All offered CANopen cards	Windows 32-Bit/64-Bit DLL Linux 32-Bit/64-Bit (Intel x86) Linux 32-Bit (ARM V7/V8)
	MTTCAN	nVidia Jetson-TX2	Linux 64-Bit (ARM V8)
	National Instruments www.ni.com/can	All offered CANopen cards	Windows 32-Bit/64-Bit DLL
	piCAN2	Raspberry Pi 2/3	Linux 32-Bit (ARM V7/V8)
PLCs [b]	Vector www.vector-informatik.de	All offered CANopen cards	Windows 32-Bit/64-Bit DLL
	Beckhoff www.beckhoff.de	All offered CANopen cards	IEC 61131-3 Beckhoff Library
Dedicated motion control masters	Siemens www.siemens.com	S7-300 with Helmholtz CAN300 Master	Delivered and supported by Helmholtz
	Helmholz www.helmholz.de		
zub machine control AG www.zub.ch	All offered MACS controllers	Commanding and configured directly by MACS application program	

[a] Interface driver of CANopen card must be installed

[b] All CAN products of other manufacturers may also be used. However, no motion control library is available

[c] Find detailed information and specifications on library usage and function calls in the separate document → «EPOS Command Library» documentation

Table 4-24 CANopen basic information | recommended components

4.3.2 Step 2: CAN Bus Wiring

The two-wire bus line must be terminated at both ends using a termination resistor of $120\ \Omega$ (a ready-made termination resistor is available with maxon P/N 662933). Twisting is recommended, shielding is suggested (depending on EMC requirements).




Figure 4-12 CAN IN connector X1 (left) and CAN OUT connector X2 (right)

CAN connectors	
CAN IN	M8, male, 5 poles, B-coded
CAN OUT	M8, female, 5 poles, B-coded

Table 4-25 CAN connectors – Specification

X2 Head A Pin	Prefab cable Color	Signal	Description
1	red	CAN_V+	CAN external supply
2	—	CAN_SHLD	Shield
3	white	CAN_H	CAN high bus line
4	blue	CAN_L	CAN low bus line
5	black	CAN_GND	Ground

Table 4-26 CAN OUT connector X2 – Pin assignment

4.3.3 Step 3: CAN Node ID

Set the Node ID using the «EPOS Studio».

Generally applicable Rules

- An unique Node ID must be defined for all devices within the CAN network.
- The Node IDs may be configured by software (changing the object “Node ID”, Index 0x2000, Subindex 0x00). The number of addressable nodes is 127.
- If you intend to operate more than one IDX with the same Node ID, you can use LSS to assign them each a unique Node ID. For details see separate document →«IDX Communication Guide», chapter “CAN Communication”; section “Layer Setting Services (LSS)”.

4.3.4 Step 4: CAN Communication

For IDX, following CAN bit rates are available:

Object "CAN Bitrate" (Index 0x2001, Subindex 0x00)	Bit rate	Max. Line Length according to CiA 102
0	1 MBit/s	25 m
1	800 kBit/s	50 m
2	500 kBit/s	100 m
3	250 kBit/s	250 m
4	125 kBit/s	500 m
(5)	reserved	–
6	50 kBit/s	1000 m
7	20 kBit/s	2500 m
(8)	not supported (10 kBit/s)	–
9	automatic bit rate detection	–

Table 4-27 CANopen basic information | CAN communication – Bit rates and line lengths

**Note**

- All devices within the CAN bus must use the same bit rate.
- If "automatic bit rate detection" is in use, at least one CANopen device (e.g. CANopen master) must be present in the network with a fixed defined CAN bit rate configuration.
- The CANopen bus' maximum bit rate depends on the cable length. Use «EPOS Studio» to configure bit rate by writing object "CAN Bit rate" (Index 0x2001, Subindex 0x00).

4.3.5 Step 5: Activate Changes

Activate changes by saving and resetting the IDX using «EPOS Studio».

- 1) Execute menu item «Save All Parameters».
- 2) Select context menu item «Reset Node» of the selected node.

4.3.6 Step 6: Communication Test

Use a CAN monitor program (supported by PC's or PLC CAN interface's manufacturer) to check wiring and configuration:

- 1) Reset all IDX devices in the bus.
- 2) Upon power on, the IDX will send a boot up message.
- 3) Make sure that all connected devices send a boot up message. If not, IDX will produce a «CAN passive mode error» (0x8120).
- 4) Boot up message:
COB-ID = 0x700 + Node ID
Data [0] = 0x00

As an example, the figure below shows the incoming message on the CAN bus (IDX Node ID = 1) displayed by a CAN monitor supplied by IXXAT.




Figure 4-13 CANopen basic information | Example: Boot up message of node 1

4.4 SDO Communication

A **Service Data Object (SDO)** reads from/writes to entries of the Object Dictionary. The SDO transport protocol allows transmission of objects of any size. SDO communication can be used to configure the IDX's object.




Figure 4-14 CANopen basic information | SDO communication

Two different transfer types are supported:

- Normal transfer: A segmented SDO protocol used to read/write objects larger than 4 bytes. This means that the transfer is split into different SDO segments (CAN frames).
- Expedited transfer: A non-segmented SDO protocol, used for objects smaller than 4 bytes.

Almost all IDX Object Dictionary entries can be read/written using the non-segmented SDO protocol (expedited transfer). Only the data recorder buffer must be read using the segmented SDO protocol (normal transfer). Thus, only non-segmented SDO protocol will be further explained. For details on the segmented protocol (normal transfer) → CANopen specification (CiA 301).

4.4.1 Expedited SDO Protocol

In the subsequent description, the terms will be used as follows:

- «**Client**» refers to the CANopen master reading or writing an object
- «**Server**» refers to the IDX (or any other CANopen slave) which reacts on the request

READING OBJECT (= SDO UPLOAD)

Client => Server	COB-ID	Data [Byte 0]	Data [Byte 1]	Data [Byte 2]	Data [Byte 3]	Data [Byte 4]	Data [Byte 5]	Data [Byte 6]	Data [Byte 7]
	0x600 + Node-ID		Index LowByte	Index HighByte	Sub- Index			Reserved	
<hr/>									
		Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
		0	1	0	X	X	X	X	X
Server => Client	COB-ID	Data [Byte 0]	Data [Byte 1]	Data [Byte 2]	Data [Byte 3]	Data [Byte 4]	Data [Byte 5]	Data [Byte 6]	Data [Byte 7]
	0x580 + Node-ID		Index LowByte	Index HighByte	Sub- Index	Object Byte 0	Object Byte 1	Object Byte 2	Object Byte 3
<hr/>									
		Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
		0	1	0	X	n	e	s	

Figure 4-15 CANopen basic information | SDO upload protocol (expedited transfer) – Read

WRITING OBJECT (= SDO DOWNLOAD)




Figure 4-16 CANopen basic information | SDO upload protocol (expedited transfer) – Write

ABORT SDO PROTOCOL (IN CASE OF ERROR)




Figure 4-17 CANopen basic information | SDO upload protocol (expedited transfer) – Abort

Note

For detailed descriptions of “Abort Codes” → FwSpec.

Legend Data [Byte 0]	
ccs	client command specifier (Bit 7...5) Read Object: ccs = 2 / Write Object: ccs = 1
scs	server command specifier (Bit 7...5) Read Object: scs = 2 / Write Object: scs = 3
cs	command specifier (Bit 7...5) SDO abort transfer: cs = 4
X	not used (always “0”)
n	Only valid if e = 1 and s = 1, otherwise 0. If valid, it indicates the number of bytes in Data [Byte 4...7] that do not contain data. Bytes [8 - n, 7] do not contain segment data.
e	Transfer type (0: normal transfer; 1: expedited transfer)
s	Size indicator (0: data set size is not indicated; 1: data set size is indicated)

Table 4-28 CANopen basic information | SDO transfer protocol – Legend

OVERVIEW ON IMPORTANT COMMAND SPECIFIER ([BYTE 0] → BIT 7...5)

Type	Length	Sending Data [Byte 0]	Receiving Data [Byte 0]
Reading Object	1 Byte	40	4F
	2 Byte	40	4B
	3 Byte	40	43
Writing Object	1 Byte	2F (or 22)	60
	2 Byte	2B (or 22)	60
	4 Byte	23 (or 22)	60
	not defined	22	60

Table 4-29 CANopen basic information | Command specifier (overview)

4.4.2 SDO Communication Examples

Read «Statusword» (Index 0x6041, Subindex 0x00) from node 1:

CANopen Sending SDO Frame			CANopen Receiving SDO Frame		
COD-ID	0x601	0x600 + Node ID	COD-ID	0x581	0x580 + Node ID
Data [0]	0x40	ccs = 2	Data [0]	0x4B	scs = 2, n = 2, e = 1, s = 1
Data [1]	0x41	Index LowByte	Data [1]	0x41	Index LowByte
Data [2]	0x60	Index HighByte	Data [2]	0x60	Index HighByte
Data [3]	0x00	Subindex	Data [3]	0x00	Subindex
Data [4]	0x00	reserved	Data [4]	0x08	Data [Byte 0]
Data [5]	0x00	reserved	Data [5]	0x00	Data [Byte 1]
Data [6]	0x00	reserved	Data [6]	0x00	reserved
Data [7]	0x00	reserved	Data [7]	0x00	reserved

Statusword: 0x0008 = 8

Table 4-30 CANopen basic information | Example “Read Statusword”

Write «Controlword» (Index 0x6040, Subindex 0x00: Data 0x000F) to node 1:

CANopen Sending SDO Frame			CANopen Receiving SDO Frame		
COD-ID	0x601	0x600 + Node ID	COD-ID	0x581	0x580 + Node ID
Data [0]	0x22	ccs = 1, n = 0, e = 1, s = 0	Data [0]	0x60	scs = 3
Data [1]	0x40	Index LowByte	Data [1]	0x40	Index LowByte
Data [2]	0x60	Index HighByte	Data [2]	0x60	Index HighByte
Data [3]	0x00	Subindex	Data [3]	0x00	Subindex
Data [4]	0x0F	Data [Byte 0]	Data [4]	0x00	reserved
Data [5]	0x00	Data [Byte 1]	Data [5]	0x00	reserved
Data [6]	0x00	reserved	Data [6]	0x00	reserved
Data [7]	0x00	reserved	Data [7]	0x00	reserved

Controlword: new value

Table 4-31 CANopen basic information | Example “Write Controlword”

Try to read the content of an object's subindex which does not exist (Index 0x2000, Subindex 0x08) from node 1:

CANopen Sending SDO Frame			CANopen Receiving SDO Frame		
COD-ID	0x601	0x600 + Node ID	COD-ID	0x581	0x580 + Node ID
Data [0]	0x40	ccs = 2	Data [0]	0x80	scs = 4
Data [1]	0x00	Index LowByte	Data [1]	0x00	Index LowByte
Data [2]	0x20	Index HighByte	Data [2]	0x20	Index HighByte
Data [3]	0x08	Subindex	Data [3]	0x08	Subindex
Data [4]	0x00	reserved	Data [4]	0x11	Abort Code [Byte 0]
Data [5]	0x00	reserved	Data [5]	0x00	Abort Code [Byte 1]
Data [6]	0x00	reserved	Data [6]	0x09	Abort Code [Byte 2]
Data [7]	0x00	reserved	Data [7]	0x06	Abort Code [Byte 3]

Abort code: 0x06090011 → the last read or write command had a wrong object subindex.

Table 4-32 CANopen basic information | Example “Read non-existent subindex”

Read «Position actual value» (Index 0x6064, Subindex 0x00) from node 1:

CANopen Sending SDO Frame			CANopen Receiving SDO Frame		
COD-ID	0x601	0x600 + Node ID	COD-ID	0x581	0x580 + Node ID
Data [0]	0x40	ccs = 2	Data [0]	0x43	scs = 2, n = 0, e = 1, s = 1
Data [1]	0x64	Index LowByte	Data [1]	0x64	Index LowByte
Data [2]	0x60	Index HighByte	Data [2]	0x60	Index HighByte
Data [3]	0x00	Subindex	Data [3]	0x00	Subindex
Data [4]	0x00	reserved	Data [4]	0xCA	Data [Byte 0]
Data [5]	0x00	reserved	Data [5]	0x04	Data [Byte 1]
Data [6]	0x00	reserved	Data [6]	0x00	Data [Byte 2]
Data [7]	0x00	reserved	Data [7]	0x00	Data [Byte 3]

Position actual value: 0x000004CA = 1226

Table 4-33 CANopen basic information | Example “Read Position actual value”

Write «Target position» (Index 0x607A, Subindex 0x00: Data 0x000008AE → 2222dec) to node 1:

CANopen Sending SDO Frame			CANopen Receiving SDO Frame		
COD-ID	0x601	0x600 + Node ID	COD-ID	0x581	0x580 + Node ID
Data [0]	0x22	ccs = 1, n = 0, e = 1, s = 0	Data [0]	0x60	scs = 3
Data [1]	0x7A	Index LowByte	Data [1]	0x7A	Index LowByte
Data [2]	0x60	Index HighByte	Data [2]	0x60	Index HighByte
Data [3]	0x00	Subindex	Data [3]	0x00	Subindex
Data [4]	0xAE	Data [Byte 0]	Data [4]	0x00	Abort Code [Byte 0]
Data [5]	0x08	Data [Byte 1]	Data [5]	0x00	Abort Code [Byte 1]
Data [6]	0x00	Data [Byte 2]	Data [6]	0x00	Abort Code [Byte 2]
Data [7]	0x00	Data [Byte 3]	Data [7]	0x00	Abort Code [Byte 3]

Target position: new value

Table 4-34 CANopen basic information | Example “Write Target position”

4.4.3 EPOS Studio Command Analyzer

If you connect the «EPOS Studio» via CANopen to the IDX, it is possible to process a CANopen command using the «EPOS Studio» tool «Command Analyzer». Thereby, a CANopen command can be executed and the sent and received data packets will be recorded.

The «Command Analyzer» is based on maxon's DLL whereby the commands are arranged similarly to the maxon Library. Thereby...

- SDOs can be sent
- PDOs cannot be processed

1) Connect «EPOS Studio» and the IDX via CAN.




Figure 4-18 CANopen basic information | Connect IDX

- 2) Open the tool «Command Analyzer».
- 3) Select «Interface» from the drop-down list «Layer Filter».




Figure 4-19 CANopen basic information | Select interface layer

COMMAND EXAMPLES

- Read Object GetObject(): Read Position Data 0x6064 0x00 32Bit (4Byte)




Figure 4-20 CANopen basic information | Command example – Read Object (= GetObject)

- Write Object SetObject(): Write Target Position 0x607A 0x00 32Bit (4Byte) 0x0000008AE (2222d)




Figure 4-21 CANopen basic information | Command example – Write Object (= SetObject)

4.5 PDO Communication

Process Data Objects (PDOs) – unconfirmed services containing no protocol overhead – are used for fast data transmission (real-time data) with a high priority. Consequently, they represent an extremely fast and flexible method to transmit data from one node to any number of other nodes. PDOs may contain up to 8 data bytes that can be specifically compiled and confirmed to suit own requirements. Each PDO has a unique identifier and is transmitted by only one node, but it can be received by more than one (producer/consumer communication).

The CANopen network management is node-oriented and follows a master/slave structure. It requires one device in the network, which serves as **NMT (Network Management) Master**. The other nodes are NMT Slaves.




Figure 4-22 CANopen basic information | Network Management (NMT)

The CANopen NMT Slave devices implement a state machine that automatically brings every device to state «Pre-Operational», once powered and initialized. In this state, the node may be configured and parameterized via SDO (e.g. using a configuration tool), PDO communication is not permitted. Thus, to switch from «Pre-Operational» to «Operational», you will need to send the “Start Remote Node Protocol”. For detailed information on NMT Services see separate document → «IDX Communication Guide».

Function	COB-ID	CS (Byte 0)	Node ID (Byte 1)	Functionality
Start Remote Node Protocol	0	0x01	0 (all)	All IDX (all CANopen nodes) will enter NMT state «Operational»
	0	0x01	n	The IDX (or CANopen node) with Node ID n will enter NMT state «Operational»
Enter Pre-Operational Protocol	0	0x80	0 (all)	All IDX (all CANopen nodes) will enter NMT state «Pre-Operational»
	0	0x80	n	The IDX (or CANopen node) with Node ID n will enter NMT state «Pre-Operational»
Enter Stopped Protocol	0	0x02	0 (all)	All IDX (all CANopen nodes) will enter NMT state «Stopped»
	0	0x02	n	The IDX (or CANopen node) with Node ID n will enter NMT state «Stopped»
Enter Reset Application Protocol	0	0x81	0 (all)	All IDX (all CANopen nodes) will enter NMT state «Reset Application»
	0	0x81	n	The IDX (or CANopen node) with Node ID n will enter NMT state «Reset Application»
Enter Reset Communication Protocol	0	0x82	0 (all)	All IDX (all CANopen nodes) will enter NMT state «Reset Communication»
	0	0x82	n	The IDX (or CANopen node) with Node ID n will enter NMT state «Reset Communication»

Table 4-35 CANopen basic information | NMT functionality




Figure 4-23 CANopen basic information | NMT slave state diagram

4.5.1 PDO Transmissions

PDO transmissions may be driven by remote requests, event triggered and actuated by Sync message received:

- Remotely requested:
Another device may initiate the transmission of an asynchronous PDO by sending a remote transmission request (remote frame).
- Event triggered (only Transmit PDOs):
An event of a mapped object (e.g. velocity changed) will cause the transmission of the TxPDO. Subindex 0x03 of object «Transmit PDO X parameter» contains the inhibit time, which represents the minimum interval for PDO transmission. The value is defined as a multiple of 100 us.
- Synchronous transmission:
In order to initiate simultaneous sampling of input values of all nodes, a periodically transmitted Sync message is required. Synchronous PDO transmission takes place in cyclic and acyclic transmission mode. Cyclic transmission means that the node waits for the Sync message after which it sends its measured values. Its PDO transmission type number (1...240) indicates the Sync rate it listens to (the number of Sync messages the node waits before next transmission of its values). The EPOS supports only Sync rates of 1.

4.5.2 PDO Mapping

Default application objects' mapping as well as the supported transmission mode is described in the Object Dictionary for each PDO. PDO identifiers may have high priority to guarantee short response time. PDO transmission is not confirmed. PDO mapping defines the application objects to be transmitted within a PDO. It describes sequence and length of the mapped application objects. A device supporting variable mapping of PDOs must support this during the state «Pre-Operational». If dynamic mapping during state «Operational» is supported, the SDO Client is responsible for data consistency.

Index	Subindex	Functionality
0x1A00	0x00	Number of mapped objects: 3
0x1A00	0x01	Mapped object 1: 0x6041 0x00 16
0x1A00	0x02	Mapped object 2: 0x6064 0x00 32
0x1A00	0x03	Mapped object 3: 0x6077 0x00 16
...
0x6041	0x00	Statusword
...
0x6064	0x00	Position actual value
...
0x6077	0x00	Torque actual value
...

Figure 4-24 CANopen basic information | PDO mapping example

4.5.3 PDO Configuration

For PDO Configuration, the device must be in state «Pre-Operational»!

The following section will explain how a configuration must be implemented step-by-step. Use the CANopen wizard in «EPOS Studio» for PDO configuration as described. For each step, an example quotes “PDO 1” and “Node 1”.

4.5.3.1 Step 1: Configure COB-ID

The default value of the COB-ID depends on the Node ID (Default COB-ID = PDO-Offset + Node ID). Otherwise, the COB-ID can be set in a defined range. Below table shows all default COB-IDs and their ranges:

Object	Index	Subindex	Default COB-ID Node 1
TxPDO 1	0x1800	0x01	0x181
TxPDO 2	0x1801	0x01	0x281
TxPDO 3	0x1802	0x01	0x381
TxPDO 4	0x1803	0x01	0x481
RxPDO 1	0x1400	0x01	0x201
RxPDO 2	0x1401	0x01	0x301
RxPDO 3	0x1402	0x01	0x401
RxPDO 4	0x1403	0x01	0x501

Table 4-36 CANopen basic information | COB-IDs – Default values and value range

Changed COB-IDs can be reset by “Restore Default PDO COB-IDs” using context menu of «CANopen Object Dictionary» view in «EPOS Studio»:

- 1) Connect «EPOS Studio» using «Wizards» \ «CANopen».




Figure 4-25 CANopen basic information | Start CANopen wizard

- 2) Select the receive PDOs by right click on «Receive PDOs» and select «Restore default COB-IDs».




Figure 4-26 CANopen basic information | Receive PDOs: Restore default COB-IDs

- 3) Select the transmit PDOs by right click on «Transmit PDOs» and select «Restore default COB-IDs».




Figure 4-27 CANopen basic information | Transmit PDOs: Restore default COB-IDs

Example: Object → “COB-ID used by RxPDO 1” (Index 0x1400, Subindex 0x01):

$$\text{Default COB ID RxPDO 1} = 0x200 + \text{Node ID} = 0x201$$

Example: Object → “COB-ID used by TxPDO 1” (Index 0x1800, Subindex 0x01):

$$\text{Default COB ID TxPDO 1} = 0x180 + \text{Node ID} = 0x181$$

4.5.3.2 Step 2: Set Transmission Type

Type 0x01	TxPDOs	Data is sampled and transmitted after the occurrence of the SYNC.
	RxPDOs	Data is passed on to the IDX and processed after the occurrence of the SYNC.
Type 0xFD	TxPDOs	Data is sampled and transmitted after the occurrence of a remote transmission request (RTR).
Type 0xFF	TxPDOs	Data is sampled and transmitted after one mapped object of the PDO has changed its value and the configured “Inhibit time” has been exceeded.
	RxPDOs	Data is transmitted (by the master to the IDX) asynchronously and then directly processed by the IDX.

Example: Object → «Transmission type RxPDO 1» (Index 0x1400, Subindex 0x02)
 Value = 0x01

4.5.3.3 Step 3: Number of Mapped Application Objects

Disable the PDO by writing a value of "0" (zero) to the subindex 0x00 holding «Number of mapped objects in...».

Example: Object → «Number of mapped objects in RxPDO 1» (Index 0x1600, Subindex 0x00)
Value = 0x00 (i.e. this PDO is disabled)

Example: Object → «Number of mapped objects in TxPDO 1» (Index 0x1A00, Subindex 0x00)
Value = 0x00 (i.e. this PDO is disabled)

4.5.3.4 Step 4: Mapping Objects

Set value from an object.

Example: Object1 → «1st mapped object in RxPDO 1» (Index 0x1600, Subindex 0x01)
Object2 → «2nd mapped object in RxPDO 1» (Index 0x1600, Subindex 0x02)

RxPDO 1	#	Mapped Object	
	1	Object_1 = 0x60400010	→ Controlword (16 Bit)
	2	Object_2 = 0x607A0020	→ Target position (32 Bit)

Note

For details on all mappable objects → FwSpec, chapters “Receive PDO... parameter” and “Transmit PDO... parameter”.

4.5.3.5 Step 5: Number of mapped Application Objects

Enable PDO by writing the value of the number of objects in object «Number of mapped objects in...».

Example: Object → «Number of mapped objects in RxPDO 1» (Index 0x1600, Subindex 0x00)

Example: Object → «Number of mapped objects in TxPDO 1» (Index 0x1A00, Subindex 0x00)

4.5.3.6 Step 6: Activate Changes

Changes will directly be activated.

Execute menu item «Save All Parameters» in the context menu of the used node («EPOS Studio» \ Navigation Window \ Workspace or Communication) or in the context menu in the view “Object Dictionary”.


4.6 Heartbeat Protocol

The IDX transmits a cyclic heartbeat message if the Heartbeat Protocol is enabled (Heartbeat Producer Time 0 = Disabled / greater than 0 = enabled). The Heartbeat Consumer guards receipt of the Heartbeat within the Heartbeat Consumer Time. If the Heartbeat Producer Time is configured in IDX, it will start immediately with the Heartbeat Protocol.



Remark

If «Automatic bite rate detection» is activated (Object 0x2001), a couple of frames must be sent first by the Master System for the IDX to synchronize to this bit rate. Only then IDX will start to send the Heartbeat Signal.



Legend: 1) Data Field / 2) Heartbeat Producer and Heartbeat Consumer Time / 3) Hearbeat Event

Figure 4-28 CANopen basic information | Heartbeat protocol – Timing diagram

DATA FIELD

Holds the NMT state. Therefore the following values for the data field are possible:

Value	IDX NMT state
0x00	Bootup
0x04	Stopped
0x05	Operational
0x7F	Pre-Operational

Table 4-37 CANopen basic information | Heartbeat protocol – Data field

HEARTBEAT PRODUCER TIME AND HEARTBEAT CONSUMER TIME

The Heartbeat Consumer Time must be longer than the Heartbeat Producer Time because of generation, sending and indication time ($HeartbeatConsumerTime \geq HeartbeatProducerTime + 20ms$). Each indication of the Master resets the Heartbeat Consumer Time.

HEARTBEAT EVENT

If IDX is in an unknown state (e.g. supply voltage failure), the Heartbeat Protocol cannot be sent to the Master. The Master will recognize this event upon elapsed Heartbeat Consumer Time and will generate a Heartbeat Event.

5 ETHERCAT COMMUNICATION & MASTER INTEGRATION

CONTENTS

In Brief	5-49
Setup of Windows Defender Firewall for EtherCAT Communication	5-50
Beckhoff TwinCAT Integration	5-57
zub MACS Integration.....	5-71
OMRON Sysmac NJ Integration.....	5-80

5.1 In Brief

OBJECTIVE

The present application note explains the necessary Firewall settings to operate EPOS4 devices with «EPOS Studio» and how to integrate them into different EtherCAT Master Environments.

SCOPE

Hardware	Order #	Firmware version	Reference
EPOS4/IDX	–	0160h	IDX Firmware Specification
IDX 56	various	0160h or higher	
IDX 70	various	0170h or higher	

Table 5-38 EtherCAT integration | Covered hardware and required documents

TOOLS

Tools	Description
Software	«EPOS Studio» Version 3.6 or higher for zub's MACS Multi-Axis EtherCAT Masters → “Required Tools” on page 5-72

Table 5-39 EtherCAT integration | Recommended tools

5.2 Setup of Windows Defender Firewall for EtherCAT Communication

This section describes how to setup the Windows Defender Firewall for EtherCAT communication.

For a Windows application to communicate with an EtherCAT network, the «Windows Defender Firewall» needs to be configured to allow sending and receiving network traffic. The required rules for an application to communicate via a EtherCAT network adapter are as follows:

- Allow inbound TCP traffic
- Allow inbound UDP traffic
- Allow outbound TCP traffic
- Allow outbound UDP traffic

You can manually create the required rules or refer to your IT department if you do not have the required permissions.

5.2.1 Add a new Firewall Rule

- 1) Open the «Windows Defender Firewall Control Panel».




Figure 5-29 EtherCAT integration – Firewall setup | Windows Defender Firewall Control Panel

2) Click «Allow an app or feature through Windows Defender Firewall».



Figure 5-30 EtherCAT integration – Firewall setup | Allow passage

3) Click «Change settings».




Figure 5-31 EtherCAT integration – Firewall setup | Change settings

4) Click «Allow another app...».




Figure 5-32 EtherCAT integration – Firewall setup | Allow app to communicate

- 5) Click **«Browse...»**.




Figure 5-33 EtherCAT integration – Firewall setup | Browse

- 6) Browse for the application executable (e.g. «EPOS Studio.exe»).
Click **«Open»**.




Figure 5-34 EtherCAT integration – Firewall setup | Select executable

7) Click «Network types...».




Figure 5-35 EtherCAT integration – Firewall setup | Select network types

8) Check both “Private” and “Public”.
Click «OK».




Figure 5-36 EtherCAT integration – Firewall setup | Choose network types

9) Click «Add».




Figure 5-37 EtherCAT integration – Firewall setup | Add network types

- 10) Verify that your App has been added to the list.
Click «OK»




Figure 5-38 EtherCAT integration – Firewall setup | Check app list

5.2.2 Modify an existing Firewall Rule

Any possibly misconfigured firewall rules might prevent the application from communication with the EtherCAT network. Modify existing rules to "allow" traffic on your network adapter's profile.

- 11) Open the «Windows Defender Firewall».
12) Click «Advanced settings»




Figure 5-39 EtherCAT integration – Firewall setup | Advanced settings

13) Click «Inbound rules»




Figure 5-40 EtherCAT integration – Firewall setup | Inbound rules

- 14) Find any entries for your application (e.g. «EPOS Studio») by verifying the “Program” path and verify their settings.
If the action is set to “Block” or if the profile does not match the EtherCAT network adapter, double-click the rule to modify it.




Figure 5-41 EtherCAT integration – Firewall setup | Set rules

- 15) Select the «General» tab.
Change the action from “Block the connection” to “Allow the connection”.
Click «OK».




Figure 5-42 EtherCAT integration – Firewall setup | Allow connection

- 16) Select the «Advanced» tab.
Check both “Private” and “Public”.
Click «OK».




Figure 5-43 EtherCAT integration – Firewall setup | Set rules

- 17) Check for any blocking outbound rules and correct them if necessary by repeating the above steps 14 through 16.

5.3 Beckhoff TwinCAT Integration

5.3.1 Integrating ESI Files

To integrate an IDX EtherCAT axis into the Beckhoff Master System, copy the ESI (EtherCAT Slave Information) XML file to the following folder. Note that the actual folder designation (****) depends on the TwinCAT version you are using:

- For **TwinCAT XAE** use path “C:\TwinCAT***3.1\Config\Io\EtherCAT”.
- For **TwinCAT2** use path “C:\TwinCAT\Io\EtherCAT”.

5.3.2 How to export the ESI File

You can export the ESI file using the «EPOS Studio»:

- 1) Make sure that the EPOS4/IDX is connected and Online.
- 2) In the Object Dictionary, click right to open the context menu, then select «Export ESI File».




Figure 5-44 EtherCAT integration – Beckhoff TwinCAT | Export ESI file

5.3.3 Scanning the EtherCAT Slave Device

- 1) Connect the IDX to the EtherCAT Master and turn on power.
- 2) Open the Beckhoff System Manager and create a new project using menu «File», then «New».
- 3) Open menu «Options», then select «Show Real Time Ethernet Compatible Devices».




Figure 5-45 EtherCAT integration – Beckhoff TwinCAT | Create new project

- 4) If “Installed and ready to use devices” does not list a network card, you will need to install the EtherCAT driver for one of the present network cards.
 - a) Click one of the listed network cards.
 - b) Click «Install».




Figure 5-46 EtherCAT integration – Beckhoff TwinCAT | Install Ethernet adapters

- 5) In the TwinCAT System Manager navigation tree, click right on «I/O Devices», then select «Scan».




Figure 5-47 EtherCAT integration – Beckhoff TwinCAT | Scan devices

- 6) Click «OK» to confirm.



Figure 5-48 EtherCAT integration – Beckhoff TwinCAT | Confirmation

- 7) All detected E/A devices (network cards) will be listed.

- Tick to select the network card to which the EtherCAT devices are connected to and untick all others.
- Click «OK».




Figure 5-49 EtherCAT integration – Beckhoff TwinCAT | New I/O devices found

- 8) Click «YES» to confirm.




Figure 5-50 EtherCAT integration – Beckhoff TwinCAT | Scan for boxes confirmation

- 9) The TwinCAT System Manager now searches for connected devices. If one or more controller were found, the following message will appear.
Click **Yes**.




Figure 5-51 EtherCAT integration – Beckhoff TwinCAT | Add drives message

- 10) Make your selection depending on the intended use:
 - Click **Yes** if you plan to use the drive as a NC-Configuration
 - Click **No** if you do not plan to use the drive a NC-Configuration
- 11) Click **Yes** to confirm.



Figure 5-52 EtherCAT integration – Beckhoff TwinCAT | Activate free run message

- 12) Save the project.




Figure 5-53 EtherCAT integration – Beckhoff TwinCAT | Save project

5.3.4 Configuration for commanding in a Cyclic Synchronous Mode

Via the EtherCAT interface, usually the following operating modes will be used:

- Cyclic Synchronous Position (CSP)
- Cyclic Synchronous Velocity (CSV)
- Cyclic Synchronous Torque (CST)

If you intend to operate the IDX in Cycle Synchronous Mode, you will need to configure PDO Mapping accordingly by defining "Slots".

Additionally, the following "regular" EPOS4/IDX operating modes may be used:

- Profile Position Mode (PPM)
- Profile Velocity Mode (PVM)

- 1) Upon recognition of the involved axes, the structure tree will be displayed (example).




Figure 5-54 EtherCAT integration – Beckhoff TwinCAT | Structure tree

- 2) Use the tab «Slots» to allocate the operating mode to be used:
 - a) Select a «Slot» from the left pane.
 - b) Select the desired operating mode from the right pane «Module».




Figure 5-55 EtherCAT integration – Beckhoff TwinCAT | Configure slots

5.3.5 Changing PDO Mapping using Beckhoff TwinCAT

- 1) Select the device in the Solution Explorer, then click the PDO you wish to edit.




Figure 5-56 EtherCAT integration – Beckhoff TwinCAT | Display process data

- 2) Click the desired preconfigured PDO mapping from the list. Click right to open the context menu.
- 3) Choose either **Delete** to remove an existing variable or **Insert** to add a new variable.




Figure 5-57 EtherCAT integration – Beckhoff TwinCAT | Select PDO

- 4) Select the object you wish to map and click **OK**.




Figure 5-58 EtherCAT integration – Beckhoff TwinCAT | Edit PDO values

VERIFY CSP SETTINGS

- 5) Enable the Distributed Clock from the EPOS4/IDX.




Figure 5-59 EtherCAT integration – Beckhoff TwinCAT | Set distributed clock

- 6) In the Solution Explorer, click on tree item «NC-Task 1 SAF», then tab «Task». Set cycle time to 2 ms.




Figure 5-60 EtherCAT integration – Beckhoff TwinCAT | Set cycle ticks 1

- 7) For **CSP** and **CSV** mode, set object 0x60C2-01 to the same value as the “Cyclic ticks” in «NC-Task 1 SAF» (→step 6). For **CST** mode, set it to zero.

Object Dictionary - EPOS4 EtherCAT					
Object Dictionary				EPOS4	
Index	SubIndex	Name	Type	Access	Value
0x6086	0x00	Motion profile type	Enum	RW	Linear ramp (trapezoidal profile)
0x6098	0x00	Homing method	Enum	RW	Home Switch Positive Speed and Index
0x6099	0x00	Homing speeds	Struct	RW	0x00 0xB5 0x00 0x00
0x609A	0x00	Homing acceleration	UInt32	RW	1000 rpm/s
0x60A8	0x00	SI unit position	Struct	RW	0x00 0xB4 0x47 0x00
0x60A9	0x00	SI unit velocity	Struct	RW	0x00 0xC0 0x03 0x00
0x60AA	0x00	SI unit acceleration	Struct	RW	0x00 0x00 0x00 0x00
0x60B0	0x00	Position offset	Int32	RW	0 inc
0x60B1	0x00	Velocity offset	Int32	RW	0 rpm
0x60B2	0x00	Torque offset	Int16	RW	0.0 %
0x60C2	0x00	Interpolation time period	Struct	RW	0x00 0x00 0x00 0x00
0x60C2	0x01	Interpolation time period value	UInt8	RW	2
0x60C2	0x02	Interpolation time index	Int8	RW	-3
0x60C5	0x00	Max acceleration	UInt32	RW	4294967295 rpm/s

Figure 5-61 EtherCAT integration – Beckhoff TwinCAT | Set cycle ticks 2

5.3.6 Configuration of the Axis

- 1) In the tab «Settings», verify that «Link To I/O...» is assigned to the EPOS4/IDX axis (naming is by your choice).




Figure 5-62 EtherCAT integration – Beckhoff TwinCAT | Link axis

- 2) In the tab «Parameter», adjust the motor speed settings as to the motor's capability and to the supply voltage.




Figure 5-63 EtherCAT integration – Beckhoff TwinCAT | Set speed settings

- 3) Set Dead Time Compensation to approximately three to four times the set NC-Task SAF Cycle ticks (→ “Verify CSP Settings” on page 5-63; step 5)




Figure 5-64 EtherCAT integration – Beckhoff TwinCAT | Set dead time compensation

- 4) Make sure to set the correct encoder resolution.




Figure 5-65 EtherCAT integration – Beckhoff TwinCAT | Set encoder settings

5) Configure the modes as follows:

SETTINGS FOR CSP MODE




Figure 5-66 EtherCAT integration – Beckhoff TwinCAT | Set CSP settings

Configure the position control loop as follows:

- Position control: Proportional Factor Kv → select a Kv factor suitable for your drive system
- Feedforward Velocity: Pre-Control Weighting [0.0...1.0] → “1.0”




Figure 5-67 EtherCAT integration – Beckhoff TwinCAT | Set position control loop settings

SETTINGS FOR CSV MODE




Figure 5-68 EtherCAT integration – Beckhoff TwinCAT | Set CSV settings

Configure the position control loop as follows:

- Position control: Proportional Factor Kv → “0.0”
- Feedforward Velocity: Pre-Control Weighting [0.0...1.0] → “1.0”




Figure 5-69 EtherCAT integration – Beckhoff TwinCAT | Set position control loop settings

In the tab «Parameter», set the correct “Output Scaling Factor (Velocity)”. Scaling may be calculated as follows:

$$\text{Scaling} = 7500 / (\text{Encoder count number} * 4)$$

e.g. Encoder with 500 counts per turn: Scaling = $7500 / (500 * 4) = 3.75$




Figure 5-70 EtherCAT integration – Beckhoff TwinCAT | Set output scaling factor

SETTINGS FOR CST MODE




Figure 5-71 EtherCAT integration – Beckhoff TwinCAT | Set CST settings

In the Solution Explorer, select **CST Outputs** and set the link for the “Target Torque” variable.




Figure 5-72 EtherCAT integration – Beckhoff TwinCAT | Set target torque

In folder **Drive\Out**, select “nDataOut2(0)” of Axis 1 as link variable.




Figure 5-73 EtherCAT integration – Beckhoff TwinCAT | Configure position control loop

Configure the position control loop as follows:

- NC-Controller Type: Position controller PID (with K_a)




Figure 5-74 EtherCAT integration – Beckhoff TwinCAT | Configure position control type

- $T_n = K_p / K_i$ (EPOS4/IDX object 0x30A1-01 and object 0x30A1-02)
- $T_v = K_d / K_p$ (EPOS4/IDX object 0x30A1-03 and object 0x30A1-01)
- K_v must be terminated empirically




Figure 5-75 EtherCAT integration – Beckhoff TwinCAT | Configure position control parameters

5.4 zub MACS Integration

OBJECTIVE

This chapter explains the required configuration of so-called «MasterMACS» or «MACS5» multi-axis motion controllers to command an EPOS4/IDX by EtherCAT.

BASICS

The MACS master controller product series of the Swiss company zub AG ([→www.zub.ch/en](http://www.zub.ch/en)) are freely programmable just as a PLC but are mainly designed for sophisticated coordination and synchronization of multi-axis drive systems. These masters can process the motion of one or multiple axis and command the EPOS4/IDX via CAN or EtherCAT.

As member of the maxon group, the company «zub machine control AG» provides you with industry-proven, high-end solutions that are supported by both maxon motor ag and zub AG.

Available are different types of masters: [→www.zub.ch/en/products/product-gallery.html](http://www.zub.ch/en/products/product-gallery.html)

The information given in this chapter refers to the following two product types. They are commanding the EPOS4/IDX in Cyclic Synchronous Position (CSP) mode via EtherCAT:

- MasterMACS
- MACS5

With other MACS product types, with other EPOS4/IDX operating modes (e.g. CSV), or for commanding via CAN (instead of EtherCAT), an adapted configuration will be required.

PRECONDITIONS

The information given in this chapter presumes that there is some level of experience present concerning the functionality and usage of zub's development environment («APOS») as well as to programming language.

The software and all manuals are free for download from zub's website:
[→www.zub.ch/en/downloads.html](http://www.zub.ch/en/downloads.html)

FUNDAMENTALS

Typical PLCs use the *:esi file and a System Manager tool to configure master and slave. The MACS software development environment does not offer such a System Manager tool. The configuration of the communication and data exchange is defined as part of the application's source code. This code section will be typically handled by an include file (*.mi) which can easily be copied into application programs. Thus, configuration can be quite simple but remains still very flexible.

The present chapter provides the code of a typical configuration of the MACS master and the EPOS4/IDX commanded via EtherCAT based on the CSP mode. You may copy/paste the required code from the document into the source code editor of the APOS development environment in use by MACS controllers.

Take note of the remarks and explanations in the code. They will help you to get a better understanding on the different configuration tasks and the possible additional motor configuration which must be checked or adapted.


REQUIRED TOOLS

Software Development Environment

APOSS

V 6.12.239 (or higher)

- Menu item Help
- About Program



EPOS Studio

V 3.6 (or higher)

- Menu item Help
- About EPOS Studio




Firmware Versions

MACS5 / MasterMACS

7.4.26 (or higher)


- Menu item Controller
- Diagnostics



EPOS4/IDX

0x160 (or higher)

- Icon
- Properties
- Version



5.4.1 EPOS4/IDX: Configuration Tasks

EPOS STUDIO'S "STARTUP WIZARD"

- 1) Configure motor, sensor, and system data.




Figure 5-76 EtherCAT integration – zub's MACS Multi-Axis EtherCAT Masters | EPOS Studio "Startup Wizard"

- 2) Conclude by pressing the "Finish" button to save all configured data in the EPOS4/IDX.

EPOS STUDIO'S "REGULATION TUNING"

- 1) Tune the current control (with or without load).
Current control parameters do not depend on the load. Therefore, current control tuning can be processed without a load.




Figure 5-77 EtherCAT integration – zub's MACS Multi-Axis EtherCAT Masters | EPOS Studio "Regulation Tuning" 1

- 2) Tune the position control loop with load.

Position control parameters depend on the load, particularly if no gear box is present. Therefore, position control tuning should be processed with the attached load.




Figure 5-78 EtherCAT integration – zub's MACS Multi-Axis EtherCAT Masters | EPOS Studio "Regulation Tuning" 2

- 3) Velocity control does not apply in CSP mode. Thus, tuning of the velocity control loop is not mandatory but recommended anyway.
- 4) Find detailed information on control tuning in the application note → chapter “2 Controller Architecture” on page 2-11.
- 5) Conclude by pressing the “Finish” button to save all configured data in the EPOS4/IDX controller.

5.4.2 MasterMACS / MACS5: Setup Tasks

MACS5 IP MODE CONFIGURATION

With a MACS5 in use, configuration of the IP mode as “EtherCAT Master” is necessary.

- Menu item: Controller
- Parameters
- Global / Axis
- Mark the radio button “EtherCAT Master”



Note

By default, the MasterMACS is configured as “EtherCAT Master”.




Figure 5-79 EtherCAT integration – zub’s MACS Multi-Axis EtherCAT Masters | MACS5 IP Mode Configuration

MACS & EPOS4/IDX: CONFIGURATION OF CONSISTENT PARAMETERS

- 1) Configure the encoder resolution of the MACS and EPOS4/IDX with matching values.
- 2) Configure the “Following error window” of the MACS parameter “POSERR” with a higher value than the EPOS4/IDX object 0x6065-00.
- 3) Ensure that configuration of the MACS’ parameter “EtherCAT SYNC period” (default: 1000 µs) and the EPOS4/IDX’s “Interpolation time period value” object 0x60C2-01 correspond to each other.
 - We recommend to keep the MACS’ default setting of 1000 µs and to configure the **EPOS4/IDX’s object 0x60C2-01 to a value of 1 ms**.
 - If the settings of this MACS and EPOS4/IDX parameters do not match, electrical noise and/or malfunction in position control may occur.

DEACTIVATION OF MACS POSITION CONTROL

The MACS position control is not required in case of EPOS4/IDX’s “Homing” or “CSP” mode. Therefore, position control can be deactivated by setting the MACS position control parameters (P, I, D) to “0” (zero), compare code extract “SetupAxisParam”.

LOCATION OF INCLUDE FILES (*.MI)

If there are include files (*.mi) in use by a program they must be located in the same directory as the application program (*.m). Otherwise, the include file will not be found by the APOSS compiler.

HOMING PROCESSED BY EPOS4/IDX

It is recommended to use the “Homing” mode of the EPOS4/IDX before activating CSP and the MACS controller to process path planning and generation of cyclic demand position updates.

- Using EPOS4/IDX’s “Homing” mode offers the possibility to use all homing methods of the EPOS4/IDX.
- Refer to separate document ➔ «IDX Firmware Specification»; chapter “Homing Mode (HMM)” to learn more about the different homing methods.

5.4.3 MACS: Configuration of EtherCAT Communication & Start-up Procedure

The initial configuration of communication and start-up procedure of the MACS can be split into different consecutive steps (functions) which can be integrated in an include file (*.mi) for usage by multiple application programs.

The typical flow of function calls will look as follows:

- 1) Initial setup tasks
 - a) Setup some base axis parameters of the MACS
➔ source code of function “**SetupAxisParam()**”
 - b) Setup CSP: Configure PDOs, SYNC period, and activate CSP mode
➔ source code of function “**SetupDriveCommandingCSP()**”
- 2) Start EtherCAT communication
 - a) Configure and initiate EtherCAT communication
➔ source code of function “**EtherCATMasterStart()**”
- 3) MACS system setup tasks
 - a) Setup the bus module
➔ source code of function “**SetupBusModule()**”
 - b) Setup virtual amplifier
➔ source code of function “**SetupVirtAmp()**”
 - c) Setup virtual counter inputs
➔ source code of function “**SetupVirtCntInp()**”

The later description provides code samples of all above mentioned functions as well as a simple application program. The source code can be copied from the document and pasted into an include file (such as “MACS-EPOS4/IDX-Config.mi”) which then initially can be called up by the application program (such as “MACS-EPOS4/IDX-Test.m”).

INITIAL SETUP TASKS: SETUPAXISPARAM(), SETUPPDOMAPPING()

```
#include "sysdef.mi" // Standardized include file by zub
#pragma NOIMPLICIT

// Setup MACS axis parameters
long SetupAxisParam(long axis, long EncCpt, long MaxRpm, long MaxAcc)
{
    // Ensure that this corresponds to the encoder and EPOS4/IDX configuration!
    set posencqc x(Axis) (EncCpt*4) // Set enc. resolution per turn [inc]
    set posencrev x(Axis) 1          // Default: 1
    set feeddist x(Axis) (EncCpt*4) // Set feed resolution (= output) per turn [inc]
    set feedrev x(Axis) 1           // Default: 1

    set velmax x(Axis) MaxRpm      // Set max. velocity [rpm]
    set rampmin x(Axis) MaxAcc     // Set max. acceleration [ms] (0- > MaxRpm)

    set kprop x(Axis) 0            // Disable P-Gain of PID-Controller
```

```

set kder x(Axis) 0           // Disable D-Gain of PID-Controller
set kint x(Axis) 0           // Disable I-Gain of PID-Controller

set poserr x(Axis) 200000    // Set max following error [inc]
// EPOS4/IDX processes position control,
// => Configuration of EPOS4/IDX's "Following Error Window" (0x6065-00) [inc]
}

// Setup CSP: Configure PDOs, SYNC period, activate OP mode
long SetupDriveCommandingCSP(long DriveId)
// DriveId is 1000000 plus the EtherCAT slave position in the bus
{
sdowritten DriveId 0x1C12 0x00 1 0x00      // Disable entry 0x1C12
sdowritten DriveId 0x1C13 0x00 1 0x00      // Disable entry 0x1C13

sdowritten DriveId 0x1A00 0 1 0      // Clear PDO 0x1A00 entries
sdowritten DriveId 0x1A00 1 4 0x60410010 // PDO 0x1A00 entry: Status
sdowritten DriveId 0x1A00 2 4 0x60640020 // PDO 0x1B00 entry: Actual position
sdowritten DriveId 0x1A00 0 1 2      // PDO 0x1A00 entry: Number of entries

sdowritten DriveId 0x1A01 0 1 0      // Clear PDO 0x1A01 entries
sdowritten DriveId 0x1A02 0 1 0      // clear PDO 0x1A02 entries
sdowritten DriveId 0x1A03 0 1 0      // clear PDO 0x1A03 entries

sdowritten DriveId 0x1600 0 1 0      // Clear PDO 0x1600 entries
sdowritten DriveId 0x1600 1 4 0x60400010 // PDO 0x1600 entry: Cmd
sdowritten DriveId 0x1600 2 4 0x607A0020 // PDO 0x1600 entry: Position set point
sdowritten DriveId 0x1600 0 1 2      // PDO 0x1600 entry: Number of entries

sdowritten DriveId 0x1601 0 1 0      // Clear PDO 0x1601 entries
sdowritten DriveId 0x1602 0 1 0      // Clear PDO 0x1602 entries
sdowritten DriveId 0x1603 0 1 0      // Clear PDO 0x1603 entries

sdowritten DriveId 0x1C12 1 2 0x1600      // PDO 0x1C12:01 index
sdowritten DriveId 0x1C12 0 1 1          // PDO 0x1C12 count

sdowritten DriveId 0x1C13 1 2 0x1A00      // PDO 0x1C13:01 index
sdowritten DriveId 0x1C13 0 1 1          // PDO 0x1C13 count

// Ensure that the EtherCAT SYNC and EPOS4/IDX interpolation time period correspond
// It is recommended to use 1 ms (which is also the default setting value of the MACS)
ecatmasterconfig 0x1000 0 1000      // MACS: EtherCAT master SYNC: 1000 us
sdowritten DriveId 0x60C2 1 0 1      // EPOS4/IDX: Interpolation time period value: 1ms

// Set EPOS4/IDX operating mode: CSP
sdowritten DriveId 0x6060 0 1 8      // CSP = mode 8
}

```

START ETHERCAT COMMUNICATION: ETHERCATMASTERSTART()

```

// Starting EtherCAT
long EtherCATMasterStart()
{
ecatmastercommand 0x1000 2      // Map Input and Output buffers (go to safeop)
ecatmastercommand 0x1000 3      // Request & wait OP state for all slaves
}

```

MACS SYSTEM SETUP TASKS: SETUPBUSMODULE(), SETUPVIRTAMP(), SETUPVIRTCNTINP()

```

// Setup bus modules
long SetupBusModule(long Axis, long PdoNumber)
{
    long busmod
    busmod = Axis-1

    BUSMOD_PARAM(busmod, BUSMOD_MODE) = 0           // delete existing bus module
    BUSMOD_PARAM(busmod, BUSMOD_BUSTYPE) = 2         // EtherCAT Master

    BUSMOD_PARAM(busmod, BUSMOD_PISRC_INPUT1) =
    VIRTAMP_PROCESS_SRCINDEX(busmod,PO_VIRTAMP_CMDWORD) // CMD Word
    BUSMOD_PARAM(busmod, BUSMOD_PISRC_INPUT2) =
    VIRTAMP_PROCESS_SRCINDEX(busmod,PO_VIRTAMP_REFPOS) // Position setpoint

    BUSMOD_PARAM(busmod, BUSMOD_TXMAP_INPUT1) = PdoNumber*0x01000000 + 2*0x00010000 + 0
    // pdo; length in bytes; bytes offset of control word
    BUSMOD_PARAM(busmod, BUSMOD_TXMAP_INPUT2) = PdoNumber*0x01000000 + 4*0x00010000 + 2
    // pdo; length in bytes; bytes offset of target position

    BUSMOD_PARAM(busmod, BUSMOD_RXMAP_POVALUE1) = PdoNumber*0x01000000 + 2*0x00010000 + 0
    // pdo ; length in bytes; bytes offset of status word
    BUSMOD_PARAM(busmod, BUSMOD_RXMAP_POVALUE2) = PdoNumber*0x01000000 + 4*0x00010000 + 2
    // pdo ; length in bytes; bytes offset of position actual value

    BUSMOD_PARAM(busmod, BUSMOD_MODE) = 2

    // Start bus module
    ecatmasterconfig (Axis) busmod 0
}

// Setup Virtual Amplifier
long SetupVirtAmp(long Axis)
{
    long modno
    modno = Axis-1

    // virtual amplifiers have a fixed connection to axes number, axe 1 use amp 0
    VIRTAMP_PARAM(modno,VIRTAMP_PISRC_CMDWORD)= AXE_PROCESS_SRCINDEX(modno,REG_CNTRLWORD)
    VIRTAMP_PARAM(modno,VIRTAMP_PISRC_REFPOS) = AXE_PROCESS_SRCINDEX(modno,REG_COMPOS)
    VIRTAMP_PARAM(modno,VIRTAMP_PISRC_REFVEL) = AXE_PROCESS_SRCINDEX(modno,REG_REFERENCE)
    VIRTAMP_PARAM(modno,VIRTAMP_PISRC_REFACC) = AXE_PROCESS_SRCINDEX(modno,PID_FFACCPART)
    VIRTAMP_PARAM(modno,VIRTAMP_PISRC_STATUS) =
    BUSMOD_PROCESS_SRCINDEX(modno,PO_BUSMOD_VALUE1)

    VIRTAMP_PARAM(modno,VIRTAMP_CNTRLW_PWROFF) = 0x06
    VIRTAMP_PARAM(modno,VIRTAMP_CNTRLW_PWRONDIS) = 0x06
    VIRTAMP_PARAM(modno,VIRTAMP_CNTRLW_PWRONENP) = 0x0F
    VIRTAMP_PARAM(modno,VIRTAMP_CNTRLW_PWRONENN) = 0x0F
    VIRTAMP_PARAM(modno,VIRTAMP_CNTRLW_QUICKSTOP) = 0x02
    VIRTAMP_PARAM(modno,VIRTAMP_CNTRLW_RESET) = 0x80
    VIRTAMP_PARAM(modno,VIRTAMP_STOPDELAY) = 0x0
    VIRTAMP_PARAM(modno,VIRTAMP_ERROR_BITMASK) = 0x0008
    VIRTAMP_PARAM(modno,VIRTAMP_ERROR_POLARITY) = 1

    VIRTAMP_PARAM(modno,VIRTAMP_MODE) = 1
    // has to be the last one because it activates all
}

```

```
}

// Setup Virtual Counter inputs
long SetupVirtCntInp()
{
    VIRTCOUNTIN_PARAM(0,VIRTCNTIN_PISRC_COUNTER)=
    BUSMOD_PROCESS_SRCINDEX(0,PO_BUSMOD_VALUE2)
    VIRTCOUNTIN_PARAM(0,VIRTCNTIN_MODE) = 3      // source is absolute and is taken as it is
}
```

5.4.4 Simple Application Program

The include file "MACS-EPOS-Config.mi" holds the functions and source code listed on the last pages. This include file must be part of the application program.

```
// Main-Program (.m File)

// Include file providing the required setup functions
#include "MACS-EPOS4/IDX-Config.mi"
// Remark: Include files have to be located in the same directory like the *.m file

long Axis, PdoNumber, DriveId, EncCpt, MaxRpm, MaxAcc

Axis = 1
PdoNumber = 1
DriveId = 1000001 // = 1000000 plus the EtherCAT slave position in the bus
EncCpt = 500 // Encoder resolution [cpt]
MaxRpm = 3000 // Max. speed [rpm]
MaxAcc = 100 // Max. acceleration [ms]: 0 -> MaxRpm

errclr // Clear all error states, if there are any present

ecatmastercommand 0x1000 0 // Disable master
ecatmastercommand 0x1000 1 // Start master

// Initial setup tasks
SetupAxisParam(Axis, EncCpt, MaxRpm, MaxAcc)
SetupDriveCommandingCSP(DriveId)

// Start EtherCAT communication
EtherCATMasterStart()

// MACS system setup tasks
SetupBusModule(Axis,PdoNumber)
SetupVirtAmp(Axis)
SetupVirtCntInp()

// Clear error states, if there are any present
Errclr // Clear MACS error states
Amperrclr x(Axis) // Clear EPOS4/IDX error states

delay(20) // Wait 20 ms
motor on x(Axis) // Enable the power stage

// Start simple cyclic movement of the motor
while(1) do
    vel x(Axis) 50 // Use 50% of MACS max. velocity
    acc x(Axis) 30 // Use 30% of MACS max. acceleration
    dec x(Axis) 30 // Use 30% of MACS max. deceleration

    // Move absolute 10 turns
    posa x(Axis) (get posencqc)*10
    delay 500 // Wait 500 ms
    posa x(Axis) 0 // Move absolute to position 0
    delay 200 // Wait 200 ms
endwhile
```

5.5 OMRON Sysmac NJ Integration

The below descriptions are based on the following items:

- Sysmac Studio Standard Edition 1.44
- NJ301-1100 (Firmware Version 1.40)

CREATING PROJECT FILE

- 1) Create a Project File from the Project Window.

ETHERCAT CONFIGURATION

- 2) In the Multiview Explorer, select «Configurations and Setup», then «EtherCAT».



Figure 5-80 EtherCAT integration – OMRON Sysmac NJ | Configuration and Setup

This will open the «Edit Pane» and will automatically create the master.




Figure 5-81 EtherCAT integration – OMRON Sysmac NJ | Master

IMPORT ESI LIBRARY

- 3) In the EtherCAT tab, click right on the master and select «Display ESI Library».




Figure 5-82 EtherCAT integration – OMRON Sysmac NJ | Import of ESI library

- 4) Click «Install (File)» to import the EPOS4/IDX ESI file.




Figure 5-83 EtherCAT integration – OMRON Sysmac NJ | Import of EPOS4/IDX ESI file

- 5) Store your settings, close and restart the «Sysmac Studio».

- 6) Select the desired EPOS4/IDX slave(s) from the **Toolbox** and Drag&Drop it (them) to the **Master** in the EtherCAT tab.




Figure 5-84 EtherCAT integration – OMRON Sysmac NJ | Slave

EPOS4/IDX PARAMETERS

- 7) In the EtherCAT tab, click right on the slave and select **Edit Module Configuration**.




Figure 5-85 EtherCAT integration – OMRON Sysmac NJ | Slave parameters

This will open a new tab named “Node1: EPOS4/IDX (xxx)”.

- 8) Select the desired operation mode from the «Toolbox» and Drag&Drop it to the respective axis in the EtherCAT tab.




Figure 5-86 EtherCAT integration – OMRON Sysmac NJ | Operation mode

- 9) Change PDO mapping «Edit PDO Map Settings».




Figure 5-87 EtherCAT integration – OMRON Sysmac NJ | PDO mapping

- 10) Change the mapping with «Add PDO Entry» or «Delete PDO Entry».




Figure 5-88 EtherCAT integration – OMRON Sysmac NJ | Change PDO mapping

- 11) Set the EtherCAT Node Address for each EPOS4 by either using the graphic (on the left) or by using the variable list (on the right). Take note that each EtherCAT node requires a unique node address.




Figure 5-89 EtherCAT integration – OMRON Sysmac NJ | Set EtherCAT node address

- 12) Go Online to set the connection method (→OMRON's «Sysmac Studio Operation Manual»).




Figure 5-90 EtherCAT integration – OMRON Sysmac NJ | Going Online

- 13) In the EtherCAT tab, click right on the master and select «Write Slave Node Address».




Figure 5-91 EtherCAT integration – OMRON Sysmac NJ | Slave node address

This will display a dialog box.




Figure 5-92 EtherCAT integration – OMRON Sysmac NJ | Write slave node address

- 14) If the node address is set correct, click «Cancel». Otherwise edit the node address and click «Write» and power off/power on the EPOS4/IDX to activate the new node address.

- 15) In the EtherCAT tab, click right on the master and select «Compare and Merge with Actual Network Configuration».




Figure 5-93 EtherCAT integration – OMRON Sysmac NJ | Network configuration

- 16) Both the actual network and Sysmac Studio configuration will be read and compared. Upon completion, the results are displayed.




Figure 5-94 EtherCAT integration – OMRON Sysmac NJ | Comparison & Merger

- 17) Click «Apply actual network configuration», then click «Close».
- 18) Go Offline.
- 19) In the Multiview Explorer, click right on «Axis Settings» and select «Add», then «Axis Settings».



Figure 5-95 EtherCAT integration – OMRON Sysmac NJ | Axis settings

- 20) Rename the axis as desired.
- 21) Go to «Axis Basic Settings» and set the following parameters:
 - Axis use = Used axis
 - Axis type = Servo axis
 - Output device 1" = Node:1, Slot : 0 CSP Mode(M1).




Figure 5-96 EtherCAT integration – OMRON Sysmac NJ | Axis basic settings

- 22) Expand the Detail Settings pane and set the respective values in the columns «Device» and «Process Data».




Figure 5-97 EtherCAT integration – OMRON Sysmac NJ | Axis detailed settings

- 23) Go to «Unit Conversion Settings» and set the following parameters:
 – pulses per motor rotation (e.g. 500 pulse encoder → 2'000 pulse/rev)
 – travel distance per motor rotation




Figure 5-98 EtherCAT integration – OMRON Sysmac NJ | Unit conversion settings

- 24) Go to «Operation Settings» and set the following parameters:
 – velocity (converting rpm → pulses/s (e.g. 10'000rpm / 60m*s *2'000 pulses = 333'333 pulses/s))
 – acceleration rate
 – deceleration rate
 – other monitor parameters




Figure 5-99 EtherCAT integration – OMRON Sysmac NJ | Operation settings

- 25) Go to **Servo Drive Settings** and set the following parameters:
 - maximum position setting
 - minimum position setting
 - main circuit power supply OFF detection to **Do not detect**.




Figure 5-100 EtherCAT integration – OMRON Sysmac NJ | Servo drive settings

PROGRAMMING

For in-depth details see OMRON's operating instruction manual → «Sysmac Studio Operation Manual (W504)».

- 26) In the Multiview Explorer, select **Programming \ POUs \ Programs \ Program0 \ Section0**.
Click right on **Section0** to add a program.




Figure 5-101 EtherCAT integration – OMRON Sysmac NJ | Add program

27) Write a short program as to the following example.




Figure 5-102 EtherCAT integration – OMRON Sysmac NJ | Example program

TASK SETTINGS

28) Go to **Program Assignment Settings** and assign the application program to the “Primary Task”.




Figure 5-103 EtherCAT integration – OMRON Sysmac NJ | Task settings

29) Go Online and download the program.

30) Click «Execute» to transfer the program to the controller.




Figure 5-104 EtherCAT integration – OMRON Sysmac NJ | Transfer to controller options

31) Click «Yes» to confirm.




Figure 5-105 EtherCAT integration – OMRON Sysmac NJ | Controller reset

••page intentionally left blank••

6 DEVICE PROGRAMMING

CONTENT

In Brief	6-93
First Step	6-94
Homing Mode (HMM)	6-95
Profile Position Mode (PPM)	6-96
Profile Velocity Mode (PVM)	6-98
Cyclic Synchronous Position Mode (CSP)	6-99
Cyclic Synchronous Velocity Mode (CSV)	6-100
Cyclic Synchronous Torque Mode (CST)	6-101
State Machine	6-102
Motion Info	6-103
Utilities	6-104

6.1 In Brief

A wide variety of operating modes permit flexible configuration of the drive system by using positioning, velocity, and current regulation. The built-in CANopen interface allows networking to multiple axes drives as well as online commanding by CAN bus master units.

Some parameters of the IDX are defined during the course of factory configuration. Therefore, the corresponding objects can no longer be changed during operation.

OBJECTIVE

The present application note explains typical commanding sequences for different operating modes based on writing/reading commands to access the Object Dictionary. For detailed information...

- on the objects itself see separate document → «IDX Firmware Specification» (subsequently referred to as “FwSpec”),
- on the command structure see separate document → «IDX Communication Guide» and → «EPOS Studio»; tool “Command Analyzer”.

SCOPE

Hardware	Order #	Firmware version	Reference
EPOS4/IDX	–	0160h	IDX Firmware Specification
IDX 56	various	0160h or higher	
IDX 70	various	0170h or higher	

Table 6-40 Device programming | Covered hardware and required documents

TOOLS

Tools	Description
Software	«EPOS Studio» Version 3.6 or higher

Table 6-41 Device programming | Recommended tools


6.2 First Step

Before the motor will be activated, motor parameters, position sensor parameters, and controller gains must be set. For detailed description → FwSpec.



Notes

- For detailed information on the command structure → «EPOS Studio» (command analyzer).
- In the later course of the present chapter, the stated units ([inc], [rpm], [rpm/s]) can vary depending on the system units configured by the objects 0x60A8, 0x60A9, and 0x60AA. All stated units correspond to their respective default configuration.



#	Object name	Object	User value [default value]
A	Node-ID	0x2000-00	User-specific [1]; typically configured by DIP switches
	CAN bit rate	0x2001-00	User-specific [0] (= 1 Mbit/s)
B	Output current limit	0x3001-02	User-specific [mA]
	Max motor speed	0x6080-00	User-specific: Motor or mechanical limits [rpm]
	Max gear input speed	0x3003-03	User-specific: Gear or mechanical limits [rpm]
C	Software position limit	0x607D-xx	User-specific [0 inc]
D	Current control parameter set: • Current controller PI gains	0x30A0-xx	Motor-specific and load-specific: Determine optimal parameter using “Regulation Tuning” in «EPOS Studio».
E	Velocity control parameter set: • Velocity controller PI gains • Velocity controller FF gains	0x30A2-xx	
	Velocity observer parameter set	0x30A3-xx	
F	Position control parameter set: • Position controller PID gains • Position controller FF gains	0x30A1-xx	

Table 6-42 Device programming | First step


6.3 Homing Mode (HMM)


Note

For details on Controlword bits (0x6040) → FwSpec.

START HOMING

The axis references to an absolute position using the selected homing method.



#	Object name	Object	User value [default value]
A	Modes of operation	0x6060-00	0x06 (Homing Mode)
B	Following error window	0x6065-00	User-specific [2'000 inc]
	Home offset move distance	0x30B1-00	User-specific [0 inc]
	Quick stop deceleration	0x6085-00	User-specific [10'000 rpm/s]
	Speed for switch search	0x6099-01	User-specific [100 rpm]
	Speed for zero search	0x6099-02	User-specific [10 rpm]
	Homing acceleration	0x609A-00	User-specific [1'000 rpm/s]
	Home position	0x30B0-00	User-specific [0 inc]
C	Homing method	0x6098-00	Select homing method (for details → FwSpec)
D	Controlword (Shutdown)	0x6040-00	0x0006
	Controlword (Switch on & Enable)	0x6040-00	0x000F
E	Controlword (Start homing)	0x6040-00	0x001F

Table 6-43 Device programming | Homing Mode (Start)


READ STATUS



Object name	Object	User value [default value]
Statusword (Target reached / Homing attained)	0x6041-00	Homing procedure is completed successfully if bit 12 ("Homing attained") is set to "1".

Table 6-44 Device programming | Homing Mode (Read)

STOP HOMING



Object name	Object	User value [default value]
Controlword (Switch on & Enable)	0x6040-00	0x000F
or		
Controlword (Halt homing)	0x6040-00	0x011F
or		
Controlword (Quick stop)	0x6040-00	0x000B

Table 6-45 Device programming | Homing Mode (Stop)

6.4 Profile Position Mode (PPM)




Note

For details on Controlword bits (0x6040) and Statusword bits (0x6041) → FwSpec.

SET POSITION

The axis moves to an absolute or relative position using a motion profile.



- [a] We recommend to check the status of the drive after an updated Controlword by a request of the Statusword (0x6041). Thereby, a delay of at least 1 ms must be respected before the Statusword is checked. For details on how to check the Statusword consult → chapter “6.10 Motion Info” on page 6-103.
- [b] Make sure to observe the delay of at least 1 ms in between Controlword commands

Table 6-46 Device programming | Profile Position Mode (Set)

READ STATUS

Object name	Object	User value [default value]
Statusword (Target reached)	0x6041-00	The axis has reached the target position if bit 10 ("Target reached") is set to "1" and bit 8 ("Halt") of the Controlword (0x6040) was not activated (for details → FwSpec).

Table 6-47 Device programming | Profile Position Mode (Read)

STOP POSITIONING

Object name	Object	User value [default value]
Controlword (Halt profile position mode)	0x6040-00	0x010F
or		
Controlword (Quick stop)	0x6040-00	0x000B

Table 6-48 Device programming | Profile Position Mode (Stop)

Read statusword

Stop positioning

6.5 Profile Velocity Mode (PVM)



Note

For details on Controlword bits (0x6040) and Statusword bits (0x6041) → FwSpec.

START VELOCITY

Motor shaft rotates with a certain speed with velocity profile.




Table 6-49 Device programming | Profile Velocity Mode (Start)

READ STATUS

Object name	Object	User value [default value]
Read statusword	Statusword (Target velocity reached)	0x6041-00 Target velocity is reached if bit 10 is set (for details → FwSpec).

Table 6-50 Device programming | Profile Velocity Mode (Read)

STOP VELOCITY

Object name	Object	User value [default value]
Stop velocity	Controlword (Halt profile velocity mode)	0x6040-00 or Controlword (Quick stop)
or		
	Controlword (Quick stop)	0x6040-00 0x000B

Table 6-51 Device programming | Profile Velocity Mode (Stop)

6.6 Cyclic Synchronous Position Mode (CSP)




Note

For details on Controlword bits (0x6040) → FwSpec.

SET POSITION

The axis moves to an absolute or relative position.



#	Object name	Object	User value [default value]
A	Modes of operation	0x6060-00	0x08 (Cyclic Synchronous Position Mode)
B	Max motor speed	0x6080-00	User-specific; motor or mechanical limits [rpm]
	Max gear input speed	0x3003-03	User-specific: Gear or mechanical limits [rpm]
	Profile deceleration [a]	0x6084-00	User-specific [10'000 rpm/s]
	Quick-stop deceleration [a]	0x6085-00	User-specific [10'000 rpm/s]
	Interpolation time period [b]	0x60C2-xx	Master's SYNC period (Cycle ticks) [1 ms]
C	Controlword (Shutdown)	0x6040-00	0x0006
	Controlword (Switch on & Enable)	0x6040-00	0x000F
D	Torque offset	0x60B2-00	Torque offset [per thousand of "Motor rated torque"; 0x6076]
	Position offset	0x60B0-00	Position offset [0 inc]
E	Target position	0x607A-00	Desired position [inc]

- [a] Deceleration values are used for stopping only, they are not used for normal operation
- [b] The «Interpolation time period value» must be configured to correspond with the master's synchronized PDO command cycle that updates the CSP set value, respectively the CSV set value.
If a value of "0" (zero) is configured, the EPOS4 immediately takes the new set value and adapts the position (in case of CSP mode), respectively the velocity (in case of CSV mode) to it within the next control cycle (i.e. 0.4 ms). Afterwards it holds this set value until the next set value of the master is received. This results in an interrupted and noisy motion if the master just provides new set values at cycle rates of 1 ms, 2 ms, or even lower.
If the «Interpolation time period value» is configured properly based on the master's PDO cycle time, the EPOS4 interpolates the new set value in between the period. This results in a smooth motion and less noisy control result.

Table 6-52 Device programming | Cyclic Synchronous Position Mode (Set)

STOP MOTION

Object name	Object	User value [default value]
Controlword (Quick stop)	0x6040-00	0x000B

Table 6-53 Device programming | Cyclic Synchronous Position Mode (Stop)

6.7 Cyclic Synchronous Velocity Mode (CSV)




Note

For details on Controlword bits (0x6040) → FwSpec.

SET VELOCITY

The axis moves with the commanded velocity.



- [a] Deceleration values are used for stopping only, they are not used for normal operation
- [b] The «Interpolation time period value» must be configured to correspond with the master's synchronized PDO command cycle that updates the CSP set value, respectively the CSV set value.
If a value of "0" (zero) is configured, the EPOS4 immediately takes the new set value and adapts the position (in case of CSP mode), respectively the velocity (in case of CSV mode) to it within the next control cycle (i.e. 0.4 ms). Afterwards it holds this set value until the next set value of the master is received. This results in an interrupted and noisy motion if the master just provides new set values at cycle rates of 1 ms, 2 ms, or even lower.
If the «Interpolation time period value» is configured properly based on the master's PDO cycle time, the EPOS4 interpolates the new set value in between the period. This results in a smooth motion and less noisy control result.

Table 6-54 Device programming | Cyclic Synchronous Velocity Mode (Set)

STOP MOTION

Object name	Object	User value [default value]
Target velocity	0x60FF-00	0x0000
or		
Controlword (Quick stop)	0x6040-00	0x000B

Table 6-55 Device programming | Cyclic Synchronous Velocity Mode (Stop)


6.8 Cyclic Synchronous Torque Mode (CST)


Note

For details on Controlword bits (0x6040) → FwSpec.

SET TORQUE

Applies a certain torque (that is: torque = current x torque constant) to the motor winding.



#	Object name	Object	User value [default value]
A	Modes of operation	0x6060-00	0x0A (Cyclic Synchronous Torque Mode)
B	Max motor speed	0x6080-00	User-specific; motor or mechanical limits [rpm]
	Max gear input speed	0x3003-03	User-specific: Gear or mechanical limits [rpm]
	Profile deceleration [a]	0x6084-00	User-specific [10'000 rpm/s]
	Quick-stop deceleration [a]	0x6085-00	User-specific [10'000 rpm/s]
C	Controlword (Shutdown)	0x6040-00	0x0006
	Controlword (Switch on & Enable)	0x6040-00	0x000F
D	Torque offset	0x60B2-00	Torque offset [per thousand of "Motor rated torque"; 0x6076]
E	Target torque	0x6071-00	Desired torque [per thousand of "Motor rated torque"; 0x6076]

[a] deceleration values are used for stopping only, they are not used for normal operation

Table 6-56 Device programming | Cyclic Synchronous Torque Mode (Set)

STOP MOTION



Object name	Object	User value [default value]
Target torque	0x6071-00	0x0000
or		
Controlword (Quick stop)	0x6040-00	0x000B

Table 6-57 Device programming | Cyclic Synchronous Torque Mode (Stop)

6.9 State Machine

CLEAR FAULT

Resetting “Fault” condition sends the Controlword with value 0x0080.

Object name	Object	User value [default value]
Clear fault	Controlword (Fault reset)	0x6040-00 0x0000;0x0080

Table 6-58 Device programming | State machine (clear fault)

SEND NMT SERVICE

Object name	Object	User value [default value]
Send NMT service	Node ID (Unique Node ID or “0” (zero) for all nodes) Command specifier: 0x01 0x02 0x80 0x81 0x82	Start remote node Stop remote node Enter pre-operational Reset node Reset communication

Table 6-59 Device programming | State machine (send NMT service)

6.10 Motion Info

GET MOVEMENT STATE

Object name	Object	User value [default value]
Read statusword	0x6041-00	The bits are partly depending on the operating mode (for details → FwSpec)

Table 6-60 Device programming | Motion info (Get movement state)

READ POSITION

Object name	Object	User value [default value]
Read position	0x6064-00	Position actual value [inc]

Table 6-61 Device programming | Motion info (Read position)

READ VELOCITY

Object name	Object	User value [default value]
Read velocity actual value averaged	0x30D3-01	Velocity actual value averaged [rpm]

Table 6-62 Device programming | Motion info (Read velocity)

READ TORQUE

Object name	Object	User value [default value]
Read torque actual value	0x6077-00	Torque actual value [per thousand of "Motor rated torque"; 0x6076]

Table 6-63 Device programming | Motion info (Read torque)

6.11 Utilities

STORE ALL PARAMETERS

Saves all parameters.

Object name	Object	User value [default value]
Save all parameters	0x1010-01	0x65766173 "save"

Table 6-64 Device programming | Utilities (Store all parameters)

RESTORE ALL DEFAULT PARAMETERS

Restores all parameters to factory settings.

Object name	Object	User value [default value]
Restore all default parameters	0x1011-01	0x64616F6C "load"

Table 6-65 Device programming | Utilities (Restore all default parameters)

LIST OF FIGURES

Figure 1-1	Documentation structure	5
Figure 2-2	Controller architecture Overview	12
Figure 2-3	Controller architecture Current regulator	12
Figure 2-4	Controller architecture Velocity regulator with feedforward	13
Figure 2-5	Controller architecture Position regulator with feedforward	17
Figure 3-6	Firmware update without «EPOS Studio» Open firmware file registration dialog	22
Figure 3-7	Firmware update without «EPOS Studio» Export program data file	23
Figure 3-8	Firmware update without «EPOS Studio» Select export directory	23
Figure 3-9	Firmware update without «EPOS Studio» Confirm export directory	23
Figure 3-10	Firmware update without «EPOS Studio» Check firmware file	23
Figure 4-11	CANopen basic information Topology with external bus termination (example)	30
Figure 4-12	CAN IN connector X1 (left) and CAN OUT connector X2 (right)	32
Figure 4-13	CANopen basic information Example: Boot up message of node 1	34
Figure 4-14	CANopen basic information SDO communication	35
Figure 4-15	CANopen basic information SDO upload protocol (expedited transfer) – Read	35
Figure 4-16	CANopen basic information SDO upload protocol (expedited transfer) – Write	36
Figure 4-17	CANopen basic information SDO upload protocol (expedited transfer) – Abort	36
Figure 4-18	CANopen basic information Connect IDX	39
Figure 4-19	CANopen basic information Select interface layer	39
Figure 4-20	CANopen basic information Command example – Read Object (= GetObject)	40
Figure 4-21	CANopen basic information Command example – Write Object (= SetObject)	40
Figure 4-22	CANopen basic information Network Management (NMT)	41
Figure 4-23	CANopen basic information NMT slave state diagram	42
Figure 4-24	CANopen basic information PDO mapping example	43
Figure 4-25	CANopen basic information Start CANopen wizard	44
Figure 4-26	CANopen basic information Receive PDOs: Restore default COB-IDs	44
Figure 4-27	CANopen basic information Transmit PDOs: Restore default COB-IDs	45
Figure 4-28	CANopen basic information Heartbeat protocol – Timing diagram	47
Figure 5-29	EtherCAT integration – Firewall setup Windows Defender Firewall Control Panel	50
Figure 5-30	EtherCAT integration – Firewall setup Allow passage	51
Figure 5-31	EtherCAT integration – Firewall setup Change settings	51
Figure 5-32	EtherCAT integration – Firewall setup Allow app to communicate	51
Figure 5-33	EtherCAT integration – Firewall setup Browse	52
Figure 5-34	EtherCAT integration – Firewall setup Select executable	52
Figure 5-35	EtherCAT integration – Firewall setup Select network types	53
Figure 5-36	EtherCAT integration – Firewall setup Choose network types	53
Figure 5-37	EtherCAT integration – Firewall setup Add network types	53
Figure 5-38	EtherCAT integration – Firewall setup Check app list	54
Figure 5-39	EtherCAT integration – Firewall setup Advanced settings	54
Figure 5-40	EtherCAT integration – Firewall setup Inbound rules	55
Figure 5-41	EtherCAT integration – Firewall setup Set rules	55

Figure 5-42	EtherCAT integration – Firewall setup Allow connection	55
Figure 5-43	EtherCAT integration – Firewall setup Set rules.....	56
Figure 5-44	EtherCAT integration – Beckhoff TwinCAT Export ESI file.....	57
Figure 5-45	EtherCAT integration – Beckhoff TwinCAT Create new project.....	58
Figure 5-46	EtherCAT integration – Beckhoff TwinCAT Install Ethernet adapters	58
Figure 5-47	EtherCAT integration – Beckhoff TwinCAT Scan devices	59
Figure 5-48	EtherCAT integration – Beckhoff TwinCAT Confirmation	59
Figure 5-49	EtherCAT integration – Beckhoff TwinCAT New I/O devices found	59
Figure 5-50	EtherCAT integration – Beckhoff TwinCAT Scan for boxes confirmation.....	59
Figure 5-51	EtherCAT integration – Beckhoff TwinCAT Add drives message.....	60
Figure 5-52	EtherCAT integration – Beckhoff TwinCAT Activate free run message	60
Figure 5-53	EtherCAT integration – Beckhoff TwinCAT Save project	60
Figure 5-54	EtherCAT integration – Beckhoff TwinCAT Structure tree	61
Figure 5-55	EtherCAT integration – Beckhoff TwinCAT Configure slots	61
Figure 5-56	EtherCAT integration – Beckhoff TwinCAT Display process data	62
Figure 5-57	EtherCAT integration – Beckhoff TwinCAT Select PDO	62
Figure 5-58	EtherCAT integration – Beckhoff TwinCAT Edit PDO values.....	63
Figure 5-59	EtherCAT integration – Beckhoff TwinCAT Set distributed clock	63
Figure 5-60	EtherCAT integration – Beckhoff TwinCAT Set cycle ticks 1	64
Figure 5-61	EtherCAT integration – Beckhoff TwinCAT Set cycle ticks 2	64
Figure 5-62	EtherCAT integration – Beckhoff TwinCAT Link axis	65
Figure 5-63	EtherCAT integration – Beckhoff TwinCAT Set speed settings	65
Figure 5-64	EtherCAT integration – Beckhoff TwinCAT Set dead time compensation	66
Figure 5-65	EtherCAT integration – Beckhoff TwinCAT Set encoder settings.....	66
Figure 5-66	EtherCAT integration – Beckhoff TwinCAT Set CSP settings	67
Figure 5-67	EtherCAT integration – Beckhoff TwinCAT Set position control loop settings	67
Figure 5-68	EtherCAT integration – Beckhoff TwinCAT Set CSV settings	67
Figure 5-69	EtherCAT integration – Beckhoff TwinCAT Set position control loop settings	68
Figure 5-70	EtherCAT integration – Beckhoff TwinCAT Set output scaling factor	68
Figure 5-71	EtherCAT integration – Beckhoff TwinCAT Set CST settings	69
Figure 5-72	EtherCAT integration – Beckhoff TwinCAT Set target torque.....	69
Figure 5-73	EtherCAT integration – Beckhoff TwinCAT Configure position control loop	69
Figure 5-74	EtherCAT integration – Beckhoff TwinCAT Configure position control type	70
Figure 5-75	EtherCAT integration – Beckhoff TwinCAT Configure position control parameters	70
Figure 5-76	EtherCAT integration – zub's MACS Multi-Axis EtherCAT Masters EPOS Studio "Startup Wizard"	73
Figure 5-77	EtherCAT integration – zub's MACS Multi-Axis EtherCAT Masters EPOS Studio "Regulation Tuning" 1 ..	73
Figure 5-78	EtherCAT integration – zub's MACS Multi-Axis EtherCAT Masters EPOS Studio "Regulation Tuning" 2 ..	73
Figure 5-79	EtherCAT integration – zub's MACS Multi-Axis EtherCAT Masters MACS5 IP Mode Configuration	74
Figure 5-80	EtherCAT integration – OMRON Sysmac NJ Configuration and Setup	80
Figure 5-81	EtherCAT integration – OMRON Sysmac NJ Master	80
Figure 5-82	EtherCAT integration – OMRON Sysmac NJ Import of ESI library	81
Figure 5-83	EtherCAT integration – OMRON Sysmac NJ Import of EPOS4/IDX ESI file	81
Figure 5-84	EtherCAT integration – OMRON Sysmac NJ Slave	82
Figure 5-85	EtherCAT integration – OMRON Sysmac NJ Slave parameters	82

Figure 5-86	EtherCAT integration – OMRON Sysmac NJ Operation mode	83
Figure 5-87	EtherCAT integration – OMRON Sysmac NJ PDO mapping	83
Figure 5-88	EtherCAT integration – OMRON Sysmac NJ Change PDO mapping.....	84
Figure 5-89	EtherCAT integration – OMRON Sysmac NJ Set EtherCAT node address	84
Figure 5-90	EtherCAT integration – OMRON Sysmac NJ Going Online	84
Figure 5-91	EtherCAT integration – OMRON Sysmac NJ Slave node address.....	85
Figure 5-92	EtherCAT integration – OMRON Sysmac NJ Write slave node address	85
Figure 5-93	EtherCAT integration – OMRON Sysmac NJ Network configuration	86
Figure 5-94	EtherCAT integration – OMRON Sysmac NJ Comparison & Merger	86
Figure 5-95	EtherCAT integration – OMRON Sysmac NJ Axis settings.....	86
Figure 5-96	EtherCAT integration – OMRON Sysmac NJ Axis basic settings	87
Figure 5-97	EtherCAT integration – OMRON Sysmac NJ Axis detailed settings	87
Figure 5-98	EtherCAT integration – OMRON Sysmac NJ Unit conversion settings.....	88
Figure 5-99	EtherCAT integration – OMRON Sysmac NJ Operation settings	88
Figure 5-100	EtherCAT integration – OMRON Sysmac NJ Servo drive settings	89
Figure 5-101	EtherCAT integration – OMRON Sysmac NJ Add program	89
Figure 5-102	EtherCAT integration – OMRON Sysmac NJ Example program	90
Figure 5-103	EtherCAT integration – OMRON Sysmac NJ Task settings	90
Figure 5-104	EtherCAT integration – OMRON Sysmac NJ Transfer to controller options.....	91
Figure 5-105	EtherCAT integration – OMRON Sysmac NJ Controller reset	91

LIST OF TABLES

Table 1-1	Notations used	6
Table 1-2	Abbreviations and acronyms used	6
Table 1-3	Brand names and trademark owners	7
Table 1-4	Sources for additional information	7
Table 2-5	Controller architecture Covered hardware and required documents	11
Table 2-6	Controller architecture Recommended tools	11
Table 2-7	Controller architecture Current regulation – Object dictionary	12
Table 2-8	Controller architecture Velocity regulation – Object dictionary	14
Table 2-9	Controller architecture Velocity observer – Object dictionary	15
Table 2-10	Controller architecture Position regulation – Object dictionary	17
Table 3-11	EtherCAT integration Covered hardware and required documents	21
Table 3-12	EtherCAT integration Recommended tools	21
Table 3-13	Firmware update without «EPOS Studio» USB – Old vs. new firmware version	24
Table 3-14	Firmware update without «EPOS Studio» CANopen – Old vs. new firmware version	24
Table 3-15	Firmware update without «EPOS Studio» EtherCAT – Old vs. new firmware version	25
Table 3-16	Firmware update without «EPOS Studio» How to prepare the controller	25
Table 3-17	Firmware update without «EPOS Studio» How to download the program data file (CiA 302-3)	26
Table 3-18	Firmware update without «EPOS Studio» How to download the program data file (FoE)	27
Table 3-19	Firmware update without «EPOS Studio» How to check identity	27
Table 3-20	Firmware update without «EPOS Studio» Objects in «Stopped» state	28
Table 3-21	Firmware update without «EPOS Studio» Objects values in «Stopped» state	28
Table 4-22	CANopen basic information Covered hardware and required documents	29
Table 4-23	CANopen basic information recommended tools	29
Table 4-24	CANopen basic information recommended components	31
Table 4-25	CAN connectors – Specification	32
Table 4-26	CAN OUT connector X2 – Pin assignment	32
Table 4-27	CANopen basic information CAN communication – Bit rates and line lengths	33
Table 4-28	CANopen basic information SDO transfer protocol – Legend	36
Table 4-29	CANopen basic information Command specifier (overview)	37
Table 4-30	CANopen basic information Example “Read Statusword”	37
Table 4-31	CANopen basic information Example “Write Controlword”	37
Table 4-32	CANopen basic information Example “Read non-existent subindex”	38
Table 4-33	CANopen basic information Example “Read Position actual value”	38
Table 4-34	CANopen basic information Example “Write Target position”	38
Table 4-35	CANopen basic information NMT functionality	41
Table 4-36	CANopen basic information COB-IDs – Default values and value range	43
Table 4-37	CANopen basic information Heartbeat protocol – Data field	47
Table 5-38	EtherCAT integration Covered hardware and required documents	49
Table 5-39	EtherCAT integration Recommended tools	49
Table 6-40	Device programming Covered hardware and required documents	93
Table 6-41	Device programming Recommended tools	93

Table 6-42	Device programming First step	94
Table 6-43	Device programming Homing Mode (Start)	95
Table 6-44	Device programming Homing Mode (Read)	95
Table 6-45	Device programming Homing Mode (Stop)	95
Table 6-46	Device programming Profile Position Mode (Set)	96
Table 6-47	Device programming Profile Position Mode (Read)	97
Table 6-48	Device programming Profile Position Mode (Stop)	97
Table 6-49	Device programming Profile Velocity Mode (Start)	98
Table 6-50	Device programming Profile Velocity Mode (Read)	98
Table 6-51	Device programming Profile Velocity Mode (Stop)	98
Table 6-52	Device programming Cyclic Synchronous Position Mode (Set)	99
Table 6-53	Device programming Cyclic Synchronous Position Mode (Stop)	99
Table 6-54	Device programming Cyclic Synchronous Velocity Mode (Set)	100
Table 6-55	Device programming Cyclic Synchronous Velocity Mode (Stop)	100
Table 6-56	Device programming Cyclic Synchronous Torque Mode (Set)	101
Table 6-57	Device programming Cyclic Synchronous Torque Mode (Stop)	101
Table 6-58	Device programming State machine (clear fault)	102
Table 6-59	Device programming State machine (send NMT service)	102
Table 6-60	Device programming Motion info (Get movement state)	103
Table 6-61	Device programming Motion info (Read position)	103
Table 6-62	Device programming Motion info (Read velocity)	103
Table 6-63	Device programming Motion info (Read torque)	103
Table 6-64	Device programming Utilities (Store all parameters)	104
Table 6-65	Device programming Utilities (Restore all default parameters)	104

INDEX

A

abbreviations & acronyms 6
 applicable EU directive 9
 applicable regulations 9

B

Beckhoff TwinCAT, integration 57
 bit rate and line length 33

C

CAN
 Bitrate 33
 bus termination 30
 communication setup 31
 ID, set 32
 Node ID, set 32
 CAN Interface Card (list of manufacturers) 31
 CANopen
 firmware update without «EPOS Studio» 24
 COB-ID, configuration 43
 command specifiers 37
 communication
 PDO 41
 SDO 35
 Communication Test of CAN network 34
 country-specific regulations 9
 current regulation (controller architecture) 12
 Cyclic Synchronous Position Mode (Device Programming) 99
 Cyclic Synchronous Torque Mode (Device Programming) 101
 Cyclic Synchronous Velocity Mode (Device Programming) 100

D

Default COB-ID 43
 device address, set 32

E

ESD 10
 ESI file (export) 57
 EtherCAT
 firmware update without «EPOS Studio» 25
 EU directive, applicable 9

F

firmware update without EPOS Studio 21

H

Heartbeat Consumer Time, calculation of 48
 Heartbeat Protocol 47
 Homing Mode (Device Programming) 95
 how to
 integrate an IDX to EtherCAT 49
 interpret icons (and signs) used in the document 6
 program operating modes 93
 update firmware without «EPOS Studio» 21

I

integration using
 Beckhoff TwinCAT 57
 OMRON Sysmac NJ 80
 zub MACS 71

L

line length and bit rate 33

M

MACS, integration 71
 Motion Info (Device Programming) 103

N

Network Management (NMT) 41
 NMT (Network Management) 41
 NMT State
 Heartbeat 47
 Node ID, set 32

O

OMRON Sysmac NJ, integration 80
 operating license 9
 operation modes with feedforward (controller architecture) 18

P

PC/CAN Interface Card (list of manufacturers) 31
 PDO (Process Data Object) 41
 PDO mapping 43
 PLC (list of manufacturers) 31
 Position Profile Mode (Device Programming) 96
 position regulation (controller architecture) 17
 prerequisites prior installation 9
 prerequisites prior programming 94
 Process Data Object (PDO) 41
 Profile Velocity Mode (Device Programming) 98

programming
Cyclic Synchronous Position Mode 99
Cyclic Synchronous Torque Mode 101
Cyclic Synchronous Velocity Mode 100
Homing Mode 95
initial steps 94
Motion Info 103
Profile Position Mode 96
Profile Velocity Mode 98
State Machine 102
Utilities 104
protective measures (ESD) 10
purpose of this document 5

R

regulation methods (controller architecture) 12
regulations, applicable 9

S

SDO (Service Data Object) 35
Service Data Object (SDO) 35
signs used 6
State Machine (Device Programming) 102
symbols used 6

T

termination resistor (662933) 32
termination resistor (CAN bus) 30
transfer protocols 35
transmission types 42
TwinCAT, integration 57

U

USB
firmware update without «EPOS Studio» 24
Utilities (Device Programming) 104

V

velocity regulation (controller architecture) 13

Z

zub MACS, integration 71



EtherCAT® is a registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany

This document is protected by copyright. Any further use (including reproduction, translation, microfilming, and other means of electronic data processing) without prior written approval is not permitted. The mentioned trademarks belong to their respective owners and are protected under intellectual property rights.

© 2021 maxon. All rights reserved. Subject to change without prior notice.

CCMC | IDX Application Notes | Edition 2021-03 | DocID rel9613

maxon motor ag
Brünigstrasse 220 +41 41 666 15 00
CH-6072 Sachseln www.maxongroup.com